

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

2000 AUTOMATIC TRANSMISSIONS

Toyota U240E Overhaul

APPLICATION

CAUTION: Vehicle is equipped with a Supplemental Restraint System (SRS). When servicing vehicle, use care to avoid accidental air bag deployment. All SRS electrical connections and wiring harness are covered with Yellow insulation. SRS-related components are located in steering column, center console, instrument panel and lower panel of instrument panel. **DO NOT** use electrical test equipment on these circuits. It may be necessary to deactivate SRS before servicing components. See **AIR BAG DEACTIVATION PROCEDURES** article in **GENERAL INFORMATION**.

AUTOMATIC TRANSAXLE APPLICATIONS

Application	Transaxle Model
Celica	U240E

IDENTIFICATION

Vehicle Identification Number (VIN) is used for correct identification of component parts and assemblies. VIN is located at top left corner of instrument panel. Vehicle certification label is located at left corner of driver's door. This label also contains the VIN.


GEAR RATIOS

TRANSAXLE GEAR RATIOS

Gear Range	Gear Ratio
1st	3.944:1
2nd	2.197:1
3rd	1.413:1
OD	1.020:1
Reverse	3.145:1

DESCRIPTION & OPERATION

The U240E transaxle is a 4-speed electronically controlled transaxle. Transaxle uses a lock-up torque converter, direct clutch, forward clutch, underdrive clutch, underdrive brake, 3 planetary gears, 2nd brake, 2 one-way clutches, 1st/reverse brake, and hydraulic and electronic control systems. See **Fig. 1**.



G00045617

Fig. 1: Identifying Transaxle Component Locations
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

LUBRICATION

RECOMMENDED FLUID

Use Toyota T-IV ATF or equivalent.

FLUID CAPACITIES

TRANSAXLE FLUID CAPACITIES ⁽¹⁾

Application	Refill - Qts. (L)	Dry Refill - Qts. (L)
U240E	4.3 (4.1)	8.0 (7.8)
(1) Capacities are approximate. Check fluid level after transaxle reaches normal operating temperature.		

ON-VEHICLE SERVICE**DRIVE AXLES**

NOTE: See appropriate article in **DRIVE AXLES**.

PARK/NEUTRAL POSITION SWITCH

NOTE: For Park/Neutral Position (PNP) switch installation and adjustment, see step 49 under **TRANSAXLE REASSEMBLY**.

VALVE BODY ASSEMBLY**Removal**


1. Remove engine undercover. Remove drain plug and drain transaxle fluid. Remove 18 oil pan bolts, oil pan and gasket. Check for steel or brass particles in oil pan. Remove 3 oil pan magnets.
2. Remove 3 bolts and oil strainer. Remove and discard "O" ring from oil strainer. Disconnect 5 shift solenoid connectors. Remove fluid temperature sensor. See **Fig. 8**. Separate wire harness from clamps. Remove 17 valve body bolts. Note bolt length and location for reassembly reference. See **Fig. 2**. Remove valve body assembly.

Installation

1. Install magnets in oil pan in original locations. Align groove in manual valve with pin in manual valve lever. Push valve body assembly against accumulator piston springs and check ball body to assist in installation. Install valve body bolts. Hand tighten 2 bolts temporarily. See **Fig. 2**. These bolts are positioning bolts.
2. Ensure valve body is aligned. Ensure bolts are installed in correct locations. For bolt length, see **VALVE BODY BOLT IDENTIFICATION** table. Tighten bolts to 97 INCH lbs. (11 N.m). Install NEW "O" ring on oil strainer. Tighten bolts to specification. See **TORQUE SPECIFICATIONS**. To complete installation, reverse removal procedure.

VALVE BODY BOLT IDENTIFICATION

Bolt Identification	Length - In. (mm)
A	.98 (25)
B	1.61 (41)
C	1.77 (45)



G00011239

Fig. 2: Identifying Valve Body Bolt Locations

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TROUBLE SHOOTING

SYMPTOM DIAGNOSIS

NOTE: No. 2 one-way clutch may also be referred to as underdrive one-way clutch.

Vehicle Does Not Move In Any Forward Or Reverse Gear

Check manual valve, primary regulator valve, parking lock pawl, front planetary gear, rear planetary gear, underdrive planetary gear, forward clutch, underdrive brake and No. 2 one-way clutch.

Vehicle Does Not Move In Reverse

Check front planetary gear, rear planetary gear, underdrive planetary gear, direct clutch, underdrive brake and 1st/reverse brake.

No 1-2 Upshift

Check lower valve body control valves, 2nd brake and No. 1 one-way clutch.

No 2-3 Upshift

Check lower valve body control valves and direct clutch.

No 3-4 Upshift

Check 3-4 shift valve and underdrive clutch.

No Lock-Up Or Lock-Up Off

Check lock-up relay valve and torque converter clutch.

No 4-3 Downshift

Check 3-4 shift valve.

No 3-2 Downshift

Check lower valve body control valves.

No 2-1 Downshift

Check lower valve body control valves.

Harsh Engagement (Neutral To Drive)

Check forward clutch accumulator, forward clutch, underdrive clutch and No. 1 one-way clutch.

Harsh Engagement (Neutral To Reverse)

Check accumulators, lower valve body control valves, direct clutch and 1st/reverse brake.

Harsh Engagement (Neutral To Low)

Check solenoid modulator valve.

Harsh Lock-Up Engagement

Check lock-up relay valve and torque converter clutch.

Harsh Engagement During Upshift

Check upper valve body check, control and lock valves.

No Engine Braking In Low

Check solenoid modulator valve and 1st/reverse brake.

No Engine Braking In "2" Position

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

Check solenoid modulator valve and 2nd brake.

No Kickdown

Check lower valve body control valves and 3-4 shift valve.

Slip Or Shudder In 1st Gear

Check No. 1 one-way clutch.

Slip Or Shudder In 2nd Gear

Check 2nd brake and No. 2 one-way clutch.

Slip Or Shudder In 3rd Gear

Check direct clutch.

Slip Or Shudder In Overdrive

Check underdrive clutch.

Slip Or Shudder In Reverse

Check direct clutch and 1st/reverse brake.

Slip Or Shudder In Forward Position After Warm-Up

Check upper valve body, oil strainer, torque converter clutch, forward clutch, direct clutch, underdrive brake, No. 1 one-way clutch and underdrive clutch.

Poor Acceleration In All Positions

Check torque converter clutch and underdrive planetary gear.

Poor Acceleration In Overdrive

Check underdrive clutch and underdrive planetary gear.

CLUTCH & BRAKE APPLICATIONS

CLUTCH & BRAKE APPLICATIONS

Selector Lever Position	Elements In Use
"D" (Drive)	
1st Gear	Forward Clutch, Underdrive Brake, No. 1 One-Way Clutch & No. 2 One-Way Clutch

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

2nd Gear	Forward Clutch, 2nd Brake, Underdrive Brake & No. 2 One-Way Clutch
3rd Gear	Direct Clutch, Forward Clutch, Underdrive Brake & No. 2 One-Way Clutch
Overdrive	Forward Clutch, Direct Clutch & Underdrive Clutch
"2" (Second)	
1st Gear	Forward Clutch, Underdrive Brake, No. 1 One-Way Clutch & No. 2 One-Way Clutch
2nd Gear	Forward Clutch, 1st/Reverse Brake, 2nd Brake, Underdrive Brake & No. 2 One-Way Clutch
"L" (Low)	Forward Clutch, 1st/Reverse Brake, Underdrive Brake, No. 1 One-Way Clutch & No. 2 One-Way Clutch
"P" (Park)	Underdrive Brake
"R" (Reverse)	Direct Clutch, Underdrive Brake & 1st/Reverse Brake
"N" (Neutral)	Underdrive Brake

PERFORMANCE TESTS

PRELIMINARY CHECK

Ensure a thorough explanation of when and how transaxle malfunction occurs is received from customer. Check fluid level and condition. Retrieve diagnostic trouble codes. See appropriate **ELECTRONIC CONTROLS** article.

Proceed as necessary. If no codes are present, proceed with symptom diagnosis. See **TROUBLE SHOOTING** . Perform **STALL SPEED TEST** under **TORQUE CONVERTER**, **TIME LAG TEST** and **HYDRAULIC PRESSURE TESTS** as needed. After repairs are completed, perform **ROAD TEST** to confirm repairs.

ROAD TEST

NOTE: Perform test at normal operating fluid temperature of 122-176°F (50-80°C).

"D" Position

1. Shift transaxle into "D" position. Hold accelerator pedal constant at full throttle. Check 1-2, 2-3, and 3-4 upshift and lock-up points. See appropriate table under **SHIFT SPEED SPECIFICATIONS** .

NOTE: There is no overdrive lock-up when coolant temperature is less than 140°F

(60°C) or when vehicle speed is 6 MPH less than the set cruise control speed. There is no lock-up when brake pedal is depressed.

- If no 1-2 upshift occurs, check lower valve body control valves or shift solenoid.
 - If no 2-3 upshift occurs, check lower valve body control valves or shift solenoid.
 - If no 3-4 upshift occurs, check 3-4 shift valve or shift solenoid.
 - If all shift points are incorrect, check upper valve body, lower valve body control valves and 3-4 shift valve.
 - If all lock-up points are incorrect, check lock-up relay valve or shift solenoid.
2. Use procedure outlined in step 1 to check for shock and slip between 1-2, 2-3, and 3-4 upshifts. If shock is harsh, line pressure may be too high. Check accumulator or check ball.
 3. Drive vehicle in "D" position lock-up or overdrive gear. Check for abnormal noise and vibration.

NOTE: Check for cause of abnormal noise and vibration must be made with extreme care as problem could be due to an unbalanced drive axle, differential, tire, torque converter, etc.

4. While driving in "D" position, confirm correct kickdown vehicle speed limits for 2-1, 3-2, 4-3 shift points. Check for abnormal shock and slip at kickdown.
5. Check lock-up function. Drive vehicle in overdrive in "D" position with lock-up on. Hold vehicle speed steady at 37 MPH. Lightly depress accelerator pedal. Ensure engine RPM does not change abruptly. Large increase in engine RPM indicates lock-up function is faulty.

"M" Position

1. Shift transaxle to "M" position. Depress accelerator pedal and press "UP" shift switch located at rear of steering wheel. Ensure transaxle upshifts to appropriate gear position each time switch is depressed. Release accelerator pedal and press "DOWN" shift switch located at front of steering wheel. Ensure transaxle downshifts to appropriate gear position each time switch is depressed. A buzzer will sound if downshift is not possible due to high vehicle speed. Reduce vehicle speed and attempt downshift. The "M" mode indicator light, located on instrument cluster, will illuminate current gear position when upshift or downshift occurs.
2. For best vehicle fuel economy and performance, upshift and downshift between 1st and 2nd gear at about 15 MPH. Upshift and downshift between 2nd and 3rd gear at about 25 MPH. Upshift and downshift between 3rd and 4th gear at about 40 MPH. Maximum allowable vehicle speed is 77 MPH in 2nd gear or 43 MPH in 1st gear. Transaxle will upshift or downshift from 1st to 4th with overdrive on, and 1st to 3rd with overdrive off. Ensure transaxle automatically downshifts to 1st gear when vehicle is stopped.
3. If "M" mode indicator light flashes, shift selector lever to "D" position and drive vehicle. If "M" mode indicator light stops flashing but remains on after selector lever is returned to "M" position, system is operating properly. If "M" mode indicator light continues to flash, fluid temperature is too low, too high, or a system malfunction exists.

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

"2" Position

1. Shift transaxle to "2" position. Drive vehicle with accelerator pedal held constantly at full throttle. Ensure 1-2 upshift points take place and are operating properly.

NOTE: In "2" position, there will be no lock-up to 2nd gear.

2. While driving in "2" position, release accelerator pedal and check engine braking effect. If there is no engine braking effect, 2nd brake is defective. Check for abnormal noise and shock at acceleration and deceleration.

"L" Position

While driving in "L" position, ensure there is no upshift to 2nd gear. While driving in "L" position, release accelerator pedal. If there is no engine braking effect, 1st/reverse brake is defective. Check for abnormal noise during acceleration and deceleration.

"R" Position

Shift transaxle into "R" position. Accelerate in Reverse from a stop at full throttle. Ensure slipping does not occur.

"P" Position

Stop vehicle on grade of more than 5 percent. Shift transaxle into "P" position. Release parking brake. Ensure parking lock pawl holds vehicle.

SHIFT SPEED SPECIFICATIONS

SHIFT SPEED SPECIFICATIONS ⁽¹⁾

Application	MPH
"D" Position	
1st-2nd	37-42
2nd-3rd	70-76
3rd-4th	111-119
3rd-4th ⁽²⁾	25-28
4th-3rd ⁽²⁾	9-12
4th-3rd	107-115
3rd-2nd	65-72
2nd-1st	27-31
"2" Position	
1st-2nd	37-42
3rd-2nd	70-76
2nd-1st	27-31
"L" Position	

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

3rd-2nd	70-76
2nd-1st	32-36
(1) Wide open throttle.	
(2) Fully closed throttle.	

LOCK-UP SPEEDS ⁽¹⁾

Application	MPH
"D" Position ⁽²⁾	
Lock-Up On in 3rd ⁽³⁾	137-145
Lock-Up Off in 3rd ⁽³⁾	137-145
Lock-Up On in OD	47-50
Lock-Up Off in OD	40-44
(1) Throttle valve opening 5 percent.	
(2) There is no lock-up in "L" or "2" position.	
(3) With OD switch off.	

TORQUE CONVERTER

Stall Speed Test

CAUTION: Perform test at normal operating fluid temperature of 122-176°F (50-80°C). DO NOT continue test for more than 10 seconds.

1. Testing is done to check overall performance of transaxle and engine by measuring maximum engine speeds in "D" and "R" positions.
2. Block front and rear wheels. Connect scan tool to Data Link Connector (DLC3) to monitor engine RPM. Apply parking and service brakes. Start engine. Shift selector lever into "D" position. Fully depress accelerator pedal. Release pedal after 10 seconds.
3. Record highest engine RPM. Compare reading obtained to specification. Stall speed should be 2220-2520. Repeat test in "R" position.
4. If stall speed is same for both positions, but lower than specified RPM, engine output may be insufficient or stator one-way clutch is not operating properly.

NOTE: If stall speed RPM is more than 600 RPM less than specification, torque converter may be faulty.


5. If stall speed in "D" position is higher than specification, forward clutch may be slipping, No. 2 one-way clutch may not be operating properly, underdrive clutch may be slipping, or line pressure is too low.
6. If stall speed in "R" position is higher than specification, direct clutch may be slipping, 1st/reverse brake may be slipping, line pressure is too low or underdrive clutch may be slipping.

7. If stall speed in "R" and "D" positions is higher than specification, line pressure is too low, incorrect fluid level exists or No. 2 one-way clutch is not operating properly.

HYDRAULIC PRESSURE TESTS

CAUTION: Perform test at normal operating fluid temperature of 122-176°F (50-80°C).

1. Ensure transaxle fluid is at operating temperature. Raise and support vehicle. Remove transaxle case test plug. See **Fig. 3** . Install hydraulic pressure gauge. Lower vehicle.
2. Fully apply parking brake. Block all wheels. Start engine and ensure idle speed is 600-700 RPM. Shift transaxle into "D" position. Read and record pressure at idle. Fully apply brakes. Depress accelerator pedal to floor. DO NOT apply full throttle for more than 5 seconds.
3. Measure highest line pressure. Refer to specifications. See **LINE PRESSURE SPECIFICATIONS** table. Repeat test in "R" position. If pressures exceed specification in all ranges, regulator valve or control valve in upper valve body is defective. Ensure no Throttle Position (TP) sensor related trouble codes are present.
4. If pressures in both positions are lower than specification, oil pump, regulator valve or underdrive clutch is defective. Ensure no TP sensor related trouble codes are present.
5. If pressure is lower than specification in "D" position only, forward clutch is defective or "D" range circuit has a fluid leak. If pressure is lower than specification in "R" position only, direct clutch is defective, 1st/reverse brake is defective or "R" range circuit has a fluid leak.



G00011240

Fig. 3: Locating Transaxle Test Plug

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

LINE PRESSURE SPECIFICATIONS

Engine RPM	"D" Range - psi (kg/cm ²)	"R" Range - psi (kg/cm ²)
Idle Speed	54-59 (3.8-4.2)	97-107 (6.9-7.5)
Stall Speed	134-139 (9.5-10.5)	255-284 (18.0-20.1)

TIME LAG TEST

CAUTION: Perform this test at normal operating fluid temperature of 122-176°F (50-80°C). Allow one minute between tests. Record 3 measurements and average results.

1. If shift lever is actuated with engine idling, a time lag will be noted before shock can be felt. This test is used for checking condition of underdrive clutch, forward clutch, direct clutch and 1st/reverse brake.
2. Apply parking brake. Connect scan tool to DLC3 to monitor engine RPM. Start engine. Ensure idle speed is 600-700 RPM with transaxle in Neutral and A/C off. Shift transaxle from "N" to "D" position. Use a stop watch to measure elapsed time between shifting lever until shock is felt.
3. Standard time lag is less than 1.2 seconds. Repeat test to measure time lag for "N" to "R" position.

Standard time lag is less than 1.5 seconds. If "N" to "D" position time lag is longer than specified, line pressure is too low, forward clutch may be worn or No. 2 one-way clutch is not operating properly.

4. If "N" to "R" position time lag is longer than specified, direct clutch may be worn, 1st/reverse brake may be worn, line pressure is too low or No. 2 one-way clutch may be worn.

COMPONENT TESTS

TORQUE CONVERTER

NOTE: Torque converter is a sealed unit and is serviced as complete assembly. Perform the following tests to check for defective converter. Torque converter and transaxle cooler must be thoroughly cleaned and flushed if transaxle is contaminated.

Torque Converter One-Way Clutch Test

1. Insert a turning tool into inner race of one-way clutch. Install Tester (09351-32010) so it fits in notch of converter hub and outer race of one-way clutch.
2. With converter in normal operating position, clutch should lock-up when turned counterclockwise and should rotate freely and smoothly when turned clockwise. See **Fig. 4**. If one-way clutch fails test in either direction, clean converter. Retest clutch. If clutch fails test, replace torque converter.




Fig. 4: Checking Torque Converter One-Way Clutch
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque Converter Sleeve Runout Test

1. Temporarily mount torque converter to drive plate. Mount a dial indicator with needle resting on converter sleeve. See **Fig. 5** . Rotate converter. If runout exceeds .012" (.30 mm), ensure converter is properly mounted to drive plate.
2. If converter is properly mounted and runout exceeds specification, replace torque converter. Mark position of converter to ensure correct installation. Remove converter from drive plate.

Drive Plate (Flexplate) Runout Test

Measure drive plate runout. See **Fig. 6** . If runout exceeds .008" (.20 mm), or if ring gear is damaged, replace drive plate. If installing a NEW drive plate, note position of spacers. Tighten bolts to 65 ft. lbs. (88 N.m).





Fig. 5: Checking Torque Converter Sleeve Runout
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G93J23811

Fig. 6: Checking Drive Plate Runout

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL & INSTALLATION

TRANSAXLE


NOTE: For transaxle removal and installation procedure, see appropriate **AUTOMATIC TRANSMISSION REMOVAL** article in **TRANSMISSION SERVICING**.

TRANSAXLE DISASSEMBLY

1. Remove nut, washer and control shift lever. Using a screwdriver, unstake lock tab. Remove 2 bolts and nut, and remove park/neutral position switch. See **Fig. 7**.
2. Remove oil line union and elbow. Remove and discard "O" rings from union and elbow (if equipped). Remove input turbine and counter gear speed sensors from top of transaxle. Remove and discard speed sensor "O" rings. Remove transaxle test plug from transaxle case. See **Fig. 3**. Remove solenoid connector bolt located above park/neutral position switch. **DO NOT** attempt to remove solenoid connector from transaxle case at this time.
3. Place transaxle on wooden blocks. Remove 18 bolts, oil pan and gasket. Disconnect 5 shift solenoid connectors. Remove bolts, clamps and fluid temperature sensor. See **Fig. 8**. Remove transaxle wiring harness with solenoid connector from transaxle case. Remove oil strainer and gasket. Remove valve body


assembly. See **VALVE BODY ASSEMBLY** under ON-VEHICLE SERVICE.

4. Remove 3 apply gaskets, check ball body and spring. See **Fig. 9** . Remove brake drum gasket, located near apply gaskets. See **Fig. 7** . Remove underdrive clutch accumulator spring. Using 57 psi (4 kg/cm²) of compressed air applied to transaxle case, remove underdrive clutch accumulator piston. See **Fig. 10** . Cover piston with shop towel during removal.




G00011241

Fig. 7: Exploded View Of Transaxle External Components
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011242

Fig. 8: Locating Fluid Temperature Sensor & Solenoid Connectors
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011243

Fig. 9: Locating Check Ball Body & Spring, & Apply Gaskets (3)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011244

Fig. 10: Removing Underdrive Clutch Accumulator Piston
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

5. Using 57 psi (4 kg/cm₂) of compressed air applied to transaxle case, remove forward clutch accumulator piston and spring, and underdrive brake accumulator piston. Cover pistons with shop towel during removal. See **Fig. 11** and **Fig. 12**.
6. Using needle nose pliers, remove manual valve lever retainer spring. Remove 2 bolts, manual detent spring and cover. See **Fig. 7**. Remove 2 bolts and parking lock pawl bracket. Using a hammer and chisel, unstake and remove spacer. Using a pin punch and hammer, drive out roll pin. Ensure pin does not fall into transaxle case.
7. Remove manual valve lever shaft and manual valve lever. Remove parking lock pawl rod from manual valve lever. Using a screwdriver, remove shaft oil seal. See **Fig. 7**. Position transaxle case with oil pump assembly facing upward.

CAUTION: Use caution when removing transaxle housing. Differential assembly

may attach to transaxle housing during removal.

8. Using a dial indicator, measure input shaft end play. See **Fig. 13** . End play should be .011-.049" (.27-1.24 mm). Remove 16 transaxle housing bolts. Note bolt length and location during removal for reassembly reference. See **Fig. 14** .




Fig. 11: Removing Forward Clutch Accumulator Piston
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




Fig. 12: Removing Underdrive Brake Accumulator Piston
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.





Fig. 13: Measuring Input Shaft End Play
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011248

Fig. 14: Removing & Installing Transaxle Housing Bolts
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


9. Remove 7 oil pump bolts and oil pump. Remove thrust bearing and bearing race from underdrive planetary gear assembly. Remove differential assembly. See **Fig. 16** . Remove 2 apply gaskets from front of transaxle case. Remove forward clutch from transaxle case. Remove multiple clutch hub and needle roller bearing from transaxle case. See **Fig. 15** .
10. Remove one bolt and parking lock pawl clamp. See **Fig. 16** . Remove parking lock pawl shaft. Push parking lock pawl toward transaxle case to prevent interference during underdrive planetary gear assembly removal. See **Fig. 17** . Using both hands, remove underdrive planetary gear assembly. DO NOT allow planetary gear assembly to separate.
11. Remove spring, pawl pin and parking lock pawl. Remove underdrive clutch assembly. See **Fig. 16** . Remove thrust bearing and bearing race. Using a screwdriver, remove No. 2 one-way clutch snap ring. Remove No. 2 one-way clutch from transaxle case. Note position of index marks on No. 2 one-way clutch for reassembly reference. See **Fig. 66** . Note position of outer race retainer on No. 2 one-way clutch for reassembly reference. See **Fig. 18** . Remove outer race retainer from No. 2 one-way clutch.
12. Using a screwdriver, remove underdrive brake snap ring. Remove flange, 4 discs and 4 plates from transaxle case. Note location of components during removal for reassembly reference. Using appropriate press, compress underdrive brake piston return spring. Using snap ring expander, remove snap ring from underdrive brake. Remove piston return spring. See **Fig. 16** .

13. Remove 11 bolts and transaxle rear cover. If necessary, tap on circumference of rear cover with plastic hammer to remove cover. Remove 2 oil seal rings from rear cover. Using appropriate puller, remove needle roller bearing, if necessary. See **Fig. 15** . Remove bolt, clamp and 2 brake apply pipes. Using a screwdriver, remove 2 apply gaskets from rear of transaxle case. See **Fig. 16** .
14. Remove direct clutch with thrust bearing from transaxle case. Remove bearing race from direct clutch (shaft side). Remove rear planetary sun gear assembly from transaxle case. Remove thrust bearing from rear planetary sun gear. Remove thrust washer No. 1 from rear planetary sun gear.
15. Remove No. 1 one-way clutch and thrust bearing from transaxle case. Remove inner race from one-way clutch. Remove one-way clutch outer sleeve from transaxle case. Note direction of components for reassembly reference. Using a screwdriver, remove 2nd brake snap ring. Remove flange, 4 discs and 4 plates from transaxle case. Note location of components during removal for reassembly reference. See **Fig. 15** .
16. Using a screwdriver, remove rear planetary gear snap ring. Remove rear planetary gear from transaxle case. Remove thrust washer No. 2 from rear planetary gear. Remove 2 bearing races, thrust bearings and front planetary sun gear from transaxle case. See **Fig. 15** .
17. Using a hammer and chisel, unstake washer located on counter drive gear. See **Fig. 15** . Ensure all claws on washer are pushed down to allow socket to fit securely on nut. Using holding tool and socket, remove nut. See **Fig. 19** . Using appropriate adapter and press, remove front planetary gear from counter drive gear. See **Fig. 20** .
18. Using a screwdriver, remove 2nd brake assembly snap ring. Remove brake hub with 2nd brake assembly. Remove brake hub from 2nd brake assembly. See **Fig. 15** . Using a screwdriver, remove snap ring and front planetary ring gear from brake hub. Remove 1st/reverse brake flange, 5 discs and 5 plates from transaxle case. Note location of components during removal for reassembly reference.

NOTE: In the following step, stop press when piston return spring cover is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents spring seat from becoming deformed. DO NOT expand snap ring excessively.


19. Using appropriate press, compress 1st/reverse brake piston return spring. Using snap ring expander, remove snap ring from underdrive brake. Remove piston return spring. Using 57 psi (4 kg/cm²) of compressed air applied to transaxle case, remove 1st/reverse brake piston from case. See **Fig. 21** . Cover piston with shop towel during removal.
20. Using appropriate adapter and press, remove counter drive gear from transaxle case. Install and tighten 2 bolts opposite each other evenly on counter drive gear. Ensure clearance between counter drive gear and bearing race is about .79" (20.0 mm). Using bearing puller, remove rear tapered roller bearing from counter drive gear. See **Fig. 15** .
21. Using a brass drift and hammer, remove bearing inner and outer races. Remove snap ring at underdrive brake piston from transaxle case. Using 57 psi (4 kg/cm²) of compressed air applied to transaxle case, remove underdrive brake piston from case. See **Fig. 22** . Cover piston with shop towel during removal.
22. Using appropriate puller, remove needle roller bearing from transaxle case. Remove 2 oil seal rings from transaxle case. See **Fig. 16** . Using appropriate puller, remove cylindrical roller bearing from transaxle case.
23. Remove oil seal ring from transaxle housing. See **Fig. 23** . Remove bolt, clamp and apply pipe from

transaxle case. Remove 3 bolts and oil deflector from transaxle case. See **Fig. 7**.




G00011249

Fig. 15: Exploded View Of Transaxle Internal Components (1 Of 2)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011250

Fig. 16: Exploded View Of Transaxle Internal Components (2 Of 2)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011251

Fig. 17: Pushing Parking Lock Pawl Toward Case
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.






Fig. 18: Removing & Installing Outer Race Retainer
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011252


Fig. 19: Removing & Installing Counter Drive Gear Nut
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011253

Fig. 20: Removing Front Planetary Gear From Counter Drive Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1st/Reverse
Brake Piston



Apply
Air Here



G00011254

Fig. 21: Removing 1st/Reverse Brake Piston
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




Fig. 22: Removing Underdrive Brake Piston
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




Fig. 23: Removing & Installing Transaxle Housing Oil Seal Ring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

COMPONENT DISASSEMBLY & REASSEMBLY

OIL PUMP ASSEMBLY

Disassembly

Using 2 screwdrivers, turn drive gear and check for smooth rotation. Remove 2 oil seal rings. Using T30 Torx socket, remove 11 bolts attaching oil pump body and stator shaft. Remove "O" ring from oil pump body. See **Fig. 24**. Note direction and location of drive and driven gears. Leave gears in oil pump body for inspection.

Inspection

1. Check body clearance of driven gear. Push driven gear to one side of body. Using a feeler gauge, measure clearance. See **Fig. 25**. Body clearance should be .003-.006" (.07-.15 mm). Maximum body clearance is .012" (.30 mm). If body clearance exceeds specification, replace oil pump body.
2. Using a feeler gauge, check tip clearance of driven gear. Measure between gear teeth and crescent-shaped part of oil pump body. See **Fig. 26**. Tip clearance should be .004-.006" (.11-.15 mm). Maximum tip

clearance is .012" (.30 mm). If tip clearance exceeds specification, replace oil pump body.

3. Check side clearance of both gears. Use a steel straightedge and feeler gauge to measure side clearance of both gears. See **Fig. 27** . Side clearance should be .0008-.0016" (.020-.040 mm). Maximum side clearance is .004" (.10 mm). Replace gears as necessary. If side clearance is not within specification after gear replacement, replace oil pump body.
4. Using a dial indicator, measure inside diameter of oil pump body bushing. See **Fig. 28** . Maximum inside diameter is 1.503" (38.18 mm). If inside diameter exceeds specification, replace oil pump body.
5. Using a dial indicator, measure inside diameter of stator shaft bushing. See **Fig. 29** . Maximum inside diameter is .849" (21.57 mm). If inside diameter exceeds specification, replace stator shaft.
6. Inspect front oil seal for cracks, damage or wear. Replace oil seal (if necessary). Remove oil seal with slide hammer. Install a NEW oil seal. Seal is properly installed when it is flush with outer edge of pump body.

Reassembly

1. Install front oil seal. Install driven gear and drive gear. Ensure top of gears are facing upward. Install stator shaft on oil pump body. Align bolt holes. Install 11 stator shaft-to-oil pump body bolts. Tighten bolts in crisscross pattern to 87 INCH lbs. (9.8 N.m).
2. Install 2 oil seal rings on oil pump. DO NOT expand ring ends excessively. Turn drive gear with screwdrivers to ensure a smooth rotation. DO NOT damage oil seal lip.





Fig. 24: Exploded View Of Oil Pump Assembly
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011257

Fig. 25: Checking Oil Pump Driven Gear Clearance
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




Fig. 26: Checking Oil Pump Driven Gear Tip Clearance
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.






Fig. 27: Checking Oil Pump Gear Side Clearance
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011260

Fig. 28: Checking Oil Pump Body Bushing Diameter
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011261

Fig. 29: Checking Stator Shaft Bushing Diameter (Multiple Clutch Hub & Underdrive Clutch Drum Bushings Are Similar)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

DIRECT CLUTCH


Disassembly

1. Prior to disassembly, measure piston stroke of direct clutch. Install direct clutch and needle roller bearing on transaxle rear cover. Using a dial indicator, measure direct clutch piston stroke by applying and releasing 57 psi (4 kg/cm²) of compressed air to transaxle rear cover. See **Fig. 30**. Piston stroke should be .024-.029" (.62-.74 mm). If piston stroke is not within specification, inspect each component during disassembly.

NOTE: In the following step, stop press when piston return spring cover is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents


spring seat from becoming deformed. DO NOT expand snap ring excessively.

2. Remove direct clutch from transaxle rear cover. Using a screwdriver, remove snap ring from direct clutch drum. Remove flange, 4 discs and 4 plates. Note location of components during removal for reassembly reference. Position clutch balancer on a press. Compress piston return springs and remove snap ring. See **Fig. 31**.
3. Remove clutch balancer and piston return springs from clutch drum. Install direct clutch on transaxle rear cover. While holding direct clutch piston, apply 57 psi (4 kg/cm²) of compressed air to transaxle rear cover to remove direct clutch piston. See **Fig. 30**.



G00045618

Fig. 30: Measuring Direct Clutch Piston Stroke
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00045619

Fig. 31: Exploded View Of Direct Clutch Assembly
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Inspection

1. Clean all parts (except discs) with solvent. Dry parts using compressed air. Inspect discs and plates for wear or burnt areas. If disc lining is peeled or discolored, replace discs as necessary. Replace all damaged components.
2. Using vernier calipers, measure direct clutch piston return spring free length with spring mounted to spring seat. Free length should be .889" (22.58 mm). Replace springs as necessary.

NOTE: New discs must be soaked in ATF at least 15 minutes prior to reassembly.

Reassembly

1. Coat piston with ATF. Using hand pressure, press piston into direct clutch drum. Ensure piston lip seal is not damaged. Install piston return springs and clutch balancer onto direct clutch drum. Set snap ring in position.

NOTE: In the following step, stop press when piston return spring cover is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents spring seat from becoming deformed. DO NOT expand snap ring excessively.

2. Using appropriate press positioned on clutch balancer, compress piston return springs. Using snap ring expander, install snap ring in direct clutch drum groove. Ensure end gap of spring is not aligned with gaps in clutch balancer hub.
3. Install 4 plates and 4 discs, starting with plate and alternating with disc. Install flange on top of disc. See **Fig. 31** . Install snap ring. Ensure end gap of snap ring is not aligned with cutouts of direct clutch drum.
4. If disc, plate or flange have been replaced, check piston stroke. Install direct clutch and needle roller bearing on transaxle rear cover. Using a dial indicator, measure direct clutch piston stroke by applying and releasing 57 psi (4 kg/cm²) of compressed air to transaxle rear cover. See **Fig. 30** .
5. Piston stroke should be .024-.029" (.62-.74 mm). If piston stroke is not within specification, disassemble and reassemble direct clutch components.
6. Measure piston stroke again. If measurement is still not within specification, replace flange. Flange is available in 6 thicknesses, from .118" (3.00 mm) to .138" (3.50 mm) in increments of .004" (.10 mm).
7. Check direct clutch operation. Insert rear planetary sun gear into direct clutch. Ensure rear planetary sun gear rotates in both directions. If sun gear does not rotate as described, disassemble and inspect direct clutch.


FORWARD CLUTCH

Disassembly

1. Prior to disassembly, measure piston stroke of forward clutch. Install forward clutch on oil pump assembly. Using a dial indicator, measure forward clutch piston stroke by applying and releasing 57 psi (4 kg/cm²) of compressed air to oil pump. See **Fig. 32** . Opening in oil pump is large. To prevent air from discharging, surround air nozzle with shop towel. Piston stroke should be .025-.041" (.63-1.04 mm). If piston stroke is not within specification, inspect each component during disassembly.
2. Remove forward clutch from oil pump assembly. Using a screwdriver, remove snap ring from forward clutch drum. Remove flange, 4 discs and 4 plates. Note location of components during removal for reassembly reference. Position clutch balancer on a press. Compress piston return springs. Using snap ring expander, remove snap ring. See **Fig. 33** .
3. Remove press, clutch balancer and piston return springs. Install forward clutch on oil pump assembly. While holding forward clutch piston, apply 57 psi (4 kg/cm²) of compressed air to oil pump to remove forward clutch piston. See **Fig. 32** . Opening in oil pump is large. To prevent air from discharging,


surround air nozzle with shop towel.

4. If piston cannot be removed using compressed air, wrap needle nose pliers tips with vinyl tape and remove piston using pliers. Remove 2 "O" rings from piston.



G00045620

Fig. 32: Measuring Forward Clutch Piston Stroke
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00045621

Fig. 33: Exploded View Of Forward Clutch Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Inspection

1. Clean all parts (except discs) with solvent. Dry parts using compressed air. Inspect discs and plates for

wear or burnt areas. If disc lining is peeled or discolored, replace discs as necessary. Replace all damaged components.

2. Using vernier calipers, measure forward clutch piston return spring free length with spring mounted to spring seat. Free length should be .854" (21.69 mm). Replace springs as necessary.
3. Using a dial indicator, measure inside diameter of multiple clutch hub bushing. See **Fig. 29** . Maximum inside diameter is .909" (23.09 mm). If inside diameter exceeds specification, replace multiple clutch hub.

NOTE: **New discs must be soaked in ATF for 15 minutes prior to reassembly.**

Reassembly

1. Coat NEW piston "O" rings with ATF. Install "O" rings on forward clutch piston. Using hand pressure, press piston into forward clutch drum. Ensure "O" rings are not damaged. Set piston return springs in position.

NOTE: **In the following step, stop press when piston return spring cover is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents spring seat from becoming deformed. DO NOT expand snap ring excessively.**

2. Install clutch balancer on spring seat. Install press on clutch balancer. Compress piston return springs. Using snap ring expander, install snap ring in forward clutch drum groove. Ensure end gap of spring is not aligned with gap in spring retainer hub
3. Install 4 plates and 4 discs, starting with plate and alternating with disc. Install flange on top of disc. See **Fig. 33** . Install snap ring. Ensure end gap of snap ring is not aligned with cutouts of forward clutch drum.
4. If disc, plate or flange have been replaced, check piston stroke. Install forward clutch on oil pump assembly. Using a dial indicator, measure forward clutch piston stroke by applying and releasing 57 psi (4 kg/cm²) of compressed air to oil pump. See **Fig. 32** . Opening in oil pump is large. To prevent air from discharging, surround air nozzle with shop towel. Piston stroke should be .025-.041" (.063-1.04 mm). If piston stroke is not within specification, disassemble and reassemble forward clutch components.
5. Measure piston stroke again. If measurement is still not within specification, replace flange. Flange is available in 5 thicknesses from .118" (3.00 mm) to .142" (3.60 mm) in increments of .006" (.15 mm). Coat thrust bearings with ATF and install.
6. Check forward clutch operation. Insert multiple clutch hub into forward clutch. Ensure forward clutch rotates in both directions. If forward clutch does not rotate as described, disassemble and inspect forward clutch.

2ND BRAKE

Disassembly & Reassembly

1. Using appropriate press, position press on piston return springs and compress springs. Using a screwdriver, remove snap ring. Remove press and piston return springs. See **Fig. 34** . While holding 2nd brake piston, apply 57 psi (4 kg/cm²) of compressed air to 2nd brake cylinder to remove piston. See **Fig. 35** . Remove 2 "O" rings from piston.

2. Using vernier calipers, measure 2nd brake piston return spring free length with spring mounted to spring seat. Free length should be .654" (16.61 mm). Replace springs as necessary. Coat NEW "O" rings with ATF and install on piston.
3. Carefully press 2nd brake piston by hand into 2nd brake cylinder. See **Fig. 34** . Using appropriate press, compress piston return springs and install snap ring. Ensure end gap of snap ring is not aligned with gap in piston return spring hub





Fig. 34: Exploded View Of 2nd Brake Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011267

Fig. 35: Removing 2nd Brake Piston

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

UNDERDRIVE PLANETARY GEAR

Disassembly

1. Using gear stand, lock nut socket, adapter and INCH-lb. torque wrench with a fulcrum length of 6.30" (160.0 mm), measure underdrive input shaft starting torque for reference. See **Fig. 36** . Starting torque should be 6.2-39.0 INCH lbs. (.7-4.4 N.m).
2. Using pin punch and hammer, loosen staked part of lock nut. Clamp underdrive planetary gear in a soft-jawed vise. Use care not to damage differential drive pinion. Using appropriate socket, remove lock nut. Remove gear from vise. Using appropriate puller, remove cylindrical roller bearing inner race. See **Fig. 37** .

3. Using gear stand and appropriate press, remove differential drive pinion, parking lock gear, counter driven gear with underdrive planetary ring gear and front tapered roller bearing. See **Fig. 37**.
4. Clamp underdrive planetary gear in soft-jawed vise. Using a hammer and chisel, cut off rear tapered roller bearing cover. Remove roller and cover. Using appropriate puller, remove rear tapered roller bearing from underdrive planetary gear. Using snap ring pliers, remove snap ring. Remove underdrive planetary ring gear from counter driven gear.





Fig. 36: Measuring Underdrive Planetary Gear Input Shaft Starting Torque
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011268

Fig. 37: Exploded View Of Underdrive Planetary Gear Assembly
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Reassembly

1. Install NEW snap ring onto tapered roller bearing outer race. Using a piston ring compressor, squeeze snap ring and install outer race into counter driven gear (if removed). Install underdrive planetary ring

gear into counter driven gear. Install snap ring. Using appropriate press, install rear tapered roller bearing onto underdrive planetary gear. Press bearing until it becomes flat at the bottom.

2. Install counter driven gear with underdrive planetary ring gear onto underdrive planetary gear. Using appropriate press, install front tapered roller bearing onto underdrive planetary gear while rotating counter driven gear.
3. Using appropriate press, install parking lock gear while rotating counter driven gear. Using press, install differential drive pinion, then install cylindrical roller bearing inner race while rotating counter driven gear.
4. Clamp underdrive planetary gear in a soft-jawed vise. Use care not to damage differential drive pinion. Using appropriate socket, install NEW lock nut and tighten to 207 ft. lbs. (280 N.m). Remove gear from vise. Using gear stand, lock nut socket, adapter and INCH-lb. torque wrench with a fulcrum length of 6.30" (160.0 mm), ensure underdrive input shaft starting torque is 6.2-39.0 INCH lbs. (.7-4.4 N.m). See **Fig. 36** . Using pin punch and hammer, stake lock nut. Ensure lock nut is not cracked.

UNDERDRIVE CLUTCH

Disassembly

1. Prior to disassembly, check piston stroke of underdrive clutch. Install underdrive clutch into transaxle case. DO NOT damage oil seal rings. Install dial indicator onto underdrive clutch flange. See **Fig. 38** . Apply and release 57 psi (4 kg/cm₂) of compressed air to transaxle case. See **Fig. 39** .
2. Piston stroke should be .058-.067" (1.47-1.69 mm). If piston stroke is not within specification, inspect discs and plates during disassembly. Using a screwdriver, remove drum snap ring. Remove flange, 3 discs and 3 plates from underdrive clutch drum. Note location of components during removal for reassembly reference. See **Fig. 40** .

NOTE: In the following step, stop press when piston return spring cover is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents spring seat from becoming deformed. DO NOT expand snap ring excessively.

3. Using appropriate press placed on clutch balancer, compress piston return springs. Using snap ring expander, remove snap ring. Remove press, clutch balancer and piston return springs.
4. Install underdrive clutch into transaxle case. DO NOT damage oil seal rings. While holding underdrive clutch piston, apply 57 psi (4 kg/cm₂) of compressed air to transaxle case to remove underdrive clutch piston. See **Fig. 39** . Remove "O" ring from underdrive clutch drum.

Inspection

1. Clean all parts (except discs) with solvent. Dry parts using compressed air. Inspect discs and plates for wear or burnt areas. If disc lining is peeled or discolored, replace discs as necessary. Replace all damaged components.
2. Using vernier calipers, measure underdrive clutch piston return spring free length with spring mounted to spring seat. Free length should be .675" (17.14 mm). Replace springs as necessary.
3. Using a dial indicator, measure inside diameter of underdrive clutch drum bushing. See **Fig. 29** .

Maximum inside diameter is 1.285" (32.64 mm). If inside diameter exceeds specification, replace underdrive clutch drum.


Reassembly

1. Coat NEW "O" ring with ATF and install on underdrive clutch drum. Coat underdrive clutch piston with ATF. Using hand pressure, install piston into underdrive clutch drum. Use care not to damage "O" ring. Install piston return springs and clutch balancer to underdrive clutch drum. Set snap ring in position.

NOTE: In the following step, stop press when piston return spring cover is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents spring seat from becoming deformed. DO NOT expand snap ring excessively.


2. Using appropriate press positioned on clutch balancer, compress piston return springs. Using snap ring expander, install snap ring in underdrive clutch drum groove. Ensure end gap of spring is not aligned with gap in clutch balancer hub.
3. Install 3 plates and 3 discs, starting with plate and alternating with disc. Install flange on top of disc. See **Fig. 40** . Install snap ring. Ensure end gap of snap ring is not aligned with cutouts of underdrive clutch drum.
4. Check underdrive clutch piston stroke. Install underdrive clutch into transaxle case. DO NOT damage oil seal rings. Install dial indicator onto underdrive clutch flange. See **Fig. 38** . Apply and release 57 psi (4 kg/cm₂) of compressed air to transaxle case. See **Fig. 39** .
5. Piston stroke should be .058-.067" (1.47-1.69 mm). If piston stroke is not within specification, replace flange. Flange is available in thicknesses of .118" (3.00 mm), .126" (3.20 mm) and .134" (3.40 mm).

Dial Indicator




G00045622

Fig. 38: Installing Dial Indicator Onto Underdrive Clutch Flange
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00045626

Fig. 39: Measuring Underdrive Clutch Piston Stroke
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00045624


Fig. 40: Exploded View Of Underdrive Clutch Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

VALVE BODY ASSEMBLY

NOTE: All valve body components must be installed in original location. Lay all components in sequence during removal for reassembly reference. Primary regulator valve position controls line pressure. Note location of primary regulator valve sleeve, plug and pin prior to disassembly. See Fig. 43 .


Disassembly

1. Remove 5 bolts and 5 shift solenoids. See **Fig. 41** and **Fig. 44** . Using snap ring pliers, remove 2 snap rings securing accumulator assemblies. Remove 2 washers, 4 springs and 2 pistons from upper valve body. See **Fig. 42** .
2. Remove 8 upper valve body bolts. See **Fig. 45** . Remove 7 upper valve body cover bolts. See **Fig. 46** . Remove bolt, cover and 2 pressure relief check balls. See **Fig. 47** .
3. Remove 7 lower valve body bolts. See **Fig. 48** . Hold plate against lower valve body and carefully remove lower valve body from upper valve body. Remove plate from lower valve body. DO NOT lose check balls. Note location of check balls, keys, plugs and pins in valve body. See **Fig. 49 -Fig. 52** .




G00011273

Fig. 41: Exploded View Of Valve Body Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011274

Fig. 42: Locating Upper Valve Body Accumulator Pistons, Check Balls & Bolts
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011275

Fig. 43: Identifying Primary Regulator Valve Position
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011276

Fig. 44: Identifying Shift Solenoid Locations
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011277

Fig. 45: Removing & Installing 8 Upper Valve Body Bolts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011278

Fig. 46: Removing & Installing Upper Valve Body Cover Bolts
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011279

Fig. 47: Locating Pressure Relief Check Balls
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011280

Fig. 48: Removing & Installing 7 Lower Valve Body Bolts
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Inspection

1. Clean all parts with solvent. Dry parts with compressed air. Ensure all valve body oil passages are clear. Inspect valves for scoring or roughness. See **Fig. 49** and **Fig. 50**. Inspect valve springs for damage, squareness, rust and collapsed coils. Measure spring free length and outer diameter.
2. Replace spring if not within specification. See appropriate VALVE BODY SPRING SPECIFICATIONS table. Ensure valve body springs correspond with appropriate valve. Ensure keys are installed in appropriate locations. See appropriate VALVE BODY KEY SPECIFICATIONS table.

VALVE BODY SPRING SPECIFICATIONS (LOWER)

Application (Color) ⁽¹⁾	Outer Diameter - In. (mm)	Free Length - In. (mm)
Direct Clutch Control Valve (Brown)	.390 (9.90)	1.346 (34.20)

2000 Toyota Celica GT**2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul**

Primary Regulator Valve (Orange)	.783 (19.90)	2.267 (57.58)
1st/Reverse Brake Control Valve (Pink)	.386 (9.80)	2.247 (57.08)
2nd Brake Control Valve (Green)	.386 (9.80)	1.912 (48.57)
3-4 Shift Valve (None)	.382 (9.70)	1.152 (29.25)
(1) For spring locations, refer to illustration. See Fig. 50 .		

VALVE BODY SPRING SPECIFICATIONS (UPPER)


Application (Color) ⁽¹⁾	Outer Diameter - In. (mm)	Free Length - In. (mm)
Clutch Apply Control Valve (Purple)	.354 (9.00)	1.586 (40.29)
Direct Clutch Exhaust Valve (Orange)	.291 (7.40)	1.585 (40.27)
Direct Clutch Lock Valve (Yellow)	.291 (7.40)	1.325 (33.66)
Lock-Up Control Valve (None)	.213 (5.40)	.944 (23.98)
Lock-Up Relay Valve (None)	.382 (9.70)	1.152 (29.27)
Secondary Regulator Valve (Blue)	.343 (8.70)	2.298 (58.36)
Solenoid Modulator Valve (Red)	.386 (9.80)	2.457 (62.40)
Underdrive Brake Orifice Control Valve (Gray)	.307 (7.80)	2.467 (62.65)
2nd Brake Lock Valve (White)	.386 (9.80)	1.473 (37.42)
(1) For spring locations, refer to illustration. See Fig. 49 .		

VALVE BODY KEY SPECIFICATIONS (LOWER)

Key I.D. Letter ⁽¹⁾	⁽²⁾ Height - In. (mm)
A	1.004 (25.50)
B, C & D	.571 (14.50)
(1) For key locations, refer to illustration. See Fig. 52 .	
(2) Thickness for key "A" is .091" (2.30 mm). Width is not available. For keys "B", "C" and "D", key width is .197" (5.00 mm). Thickness is .126" (3.20 mm).	


VALVE BODY KEY SPECIFICATIONS (UPPER)

Key I.D. Letter ⁽¹⁾	⁽²⁾ Height - In. (mm)
A, B & D	.394 (10.00)
F	.728 (18.50)
All Other Keys	.315 (8.00)
(1) For key locations, refer to illustration. See Fig. 51 .	
(2) Thickness for key "F" is .091" (2.30 mm). Width is not available. For all other keys, width is .197" (5.00 mm). Thickness is .126" (3.20 mm).	




G00011281

Fig. 49: Exploded View Of Upper Valve Body
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011282

Fig. 50: Exploded View Of Lower Valve Body
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011283

Fig. 51: Identifying Upper Valve Body Check Ball & Key Locations
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011284

Fig. 52: Identifying Lower Valve Body Check Ball & Key Locations
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Reassembly

1. Install check balls in upper and lower valve bodies. Ensure check balls are installed in correct locations. See **Fig. 51** and **Fig. 52** . Install plate to lower valve body. Install lower valve body with plate to upper valve body. Install 7 lower valve body bolts and tighten to 97 INCH lbs. (11 N.m). Bolts are 1.614" (41.00 mm) in length.
2. Install accumulator pistons, springs, washers and snap rings. Ensure spring free length and outer diameter are within specification. For spring specifications, see **ACCUMULATOR VALVE SPRING SPECIFICATIONS** table. Ensure components are installed in correct locations. Install pressure relief check balls, retainer and bolt. Tighten bolt to 97 INCH lbs. (11 N.m). See **Fig. 47** .
3. Turn valve body over. Install 7 upper valve body cover bolts. Tighten bolts to 58 INCH lbs. (6.6 N.m). Install 8 upper valve body bolts. Tighten bolts to 97 INCH lbs. (11 N.m). Ensure bolts are installed in

correct locations. For bolt identification, see **UPPER VALVE BODY BOLT IDENTIFICATION** table.

4. Install 5 shift solenoids and bolts. Tighten shift solenoid SLT and SL1 bolts to 58 INCH lbs. (6.6 N.m). Bolt length is .47" (12.0 mm). Tighten all other shift solenoid bolts to 97 INCH lbs. (11 N.m). Bolt length is 1.77" (45.0 mm). See **Fig. 44** . Ensure primary regulator valve is installed in correct position. See **Fig. 43** .

ACCUMULATOR VALVE SPRING SPECIFICATIONS

Application (Color)	Free Length - In. (mm)	Outer Diameter - In. (mm)
Direct Clutch Accumulator		
Inner Spring (Brown)	1.873 (47.58)	.441 (11.20)
Outer Spring (Brown)	1.874 (47.61)	.472 (12.00)
2nd Brake Accumulator		
Inner Spring (Purple)	1.728 (43.88)	.433 (11.00)
Outer Spring (White)	1.776 (45.12)	.465 (11.80)


UPPER VALVE BODY BOLT IDENTIFICATION

Application	In. (mm)
Cover Bolt ⁽¹⁾	
Bolt A	.591 (15.00)
Bolt B	.394 (10.00)
Upper Valve Body Bolt ⁽²⁾	
Bolt A	1.614 (41.00)
Bolt B	1.181 (30.00)
(1) For cover bolt locations, refer to illustration. See Fig. 46 .	
(2) For upper valve body bolt locations, refer to illustration. See Fig. 45 .	

DIFFERENTIAL ASSEMBLY


Disassembly

1. Perform pre-disassembly inspection. Position dial indicator assembly on transaxle case. Position dial indicator tip against side gear. See **Fig. 54** . Measure side gear backlash while holding one pinion gear toward case. Backlash should be .002-.008" (.05-.20 mm). Note and record reading.
2. Mark ring gear and differential case for reassembly reference. Unstake lock plates on ring gear bolts. Remove 4 lock plates and 8 ring gear bolts. Using a plastic hammer, tap on ring gear to remove it from differential case. See **Fig. 53** .
3. Using appropriate puller, remove front and rear tapered roller bearings (if necessary). Using a pin punch and hammer, drive out pinion shaft pin from ring gear side of case. Remove differential pinion shaft from differential case.
4. Remove 2 differential pinion gears, side gears, and 4 thrust washers. Using appropriate puller, remove side gear bearing outer races and shim from transaxle housing and transaxle case. Remove oil seals from transaxle housing and transaxle case.



G00011285

Fig. 53: Exploded View Of Differential Assembly
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011286

Fig. 54: Measuring Side Gear Backlash

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Cleaning & Inspection


Clean all parts with solvent. Dry with compressed air. Check bearings, races and gears for wear or damage. Replace if necessary.

Reassembly

1. Install original shim (if removed) into transaxle case. Using appropriate race installer and hammer, install outer race into transaxle housing and transaxle case (if removed). Drive outer races in until shim and outer race contact housing or case surface.
2. Coat thrust washers, side gears and pinion gears with ATF. Install 2 thrust washers onto 2 differential side gears. Install 2 thrust washers with 2 side gears, and 2 thrust washers with pinion gears into differential case. Install pinion shaft, aligning lock pin holes on pinion shaft and differential case.
3. Mount differential case in a soft-jawed vise. Using a dial indicator, check side gear backlash. Hold one pinion gear against case. Measure side gear backlash. See **Fig. 54**. Backlash must be .002-.008" (.05-.20 mm). If backlash is not within specification, side gear thrust washers must be replaced.
4. Select thrust washers that will ensure correct side gear backlash. Thrust washers are available in

thicknesses of .037-.047" (.95-1.20 mm) in .002" (.05 mm) increments. Install thrust washers and side gears in differential case. If possible, install same size thrust washers on both sides. Install pinion gears and pinion shaft. Check side gear backlash to ensure proper thrust washers are used.

5. Using a pin punch and hammer, drive pinion shaft pin through transaxle case and pinion shaft. Stake differential case. Using appropriate press, install differential case tapered roller bearings.
6. Remove any material from transaxle housing and case mating surfaces. DO NOT allow oil to contact surfaces. Install differential assembly into transaxle case. Install transaxle housing onto transaxle case. Install 16 transaxle housing bolts. Apply thread sealant to 5 lower bolts inside torque converter housing, and tighten these bolts to 16 ft. lbs. (22 N.m) within 10 minutes of installation. Tighten all other bolts to 22 ft. lbs. (29 N.m). Ensure bolts are in correct locations. Longest bolts go inside torque converter housing. See **Fig. 14**.
7. Using appropriate adapter and ratchet, rotate differential assembly in both directions to seat bearings. Using an INCH-lb. torque wrench, measure differential side bearing preload. See **Fig. 55**. Preload should be 9.0-14.0 INCH lbs. (1.0-1.6 N.m) for NEW bearings and 4.4-7.1 INCH lbs. (.5-.8 N.m) for used bearings.
8. If preload is not within specification, remove 16 transaxle housing bolts. Using a plastic hammer, remove transaxle housing from transaxle case. Remove differential assembly from transaxle case and replace shim at rear tapered roller bearing with appropriate shim.
9. Adjustment shims are marked in numeric and alphabetic order and available in thicknesses from .114 (2.90 mm), marked with a zero, to .132" (3.35 mm), marked with the number "9", and from .134" (3.40 mm), marked with the letter "A", to .150" (3.80 mm), marked with the letter "H". Shims increase in increments of .002" (.05 mm). Recheck preload after shim replacement.
10. Clean contact surface of differential case and ring gear using cleaning solvent. Heat ring gear to 212°F (100°C) in water. DO NOT heat ring gear above 230°F (110 °C).
11. After moisture on ring gear has completely evaporated, quickly align match marks made during disassembly. Install ring gear on differential case. Install lock plates and ring gear bolts and tighten to 71 ft. lbs. (96 N.m). Install NEW oil seals in transaxle housing and transaxle case. Coat lip of oil seals with lubricant. Ensure transaxle case oil seal depth is .087-.126" (2.20-3.20 mm) from case lip.



G00011287

Fig. 55: Measuring Side Bearing Preload (Typical)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TRANSAXLE REASSEMBLY

NOTE: Coat all oil seal rings, clutch discs, clutch plates, rotating parts and sliding surfaces with ATF prior to reassembly. All gaskets and rubber "O" rings should be replaced. Ensure ends of snap rings are not aligned with cutouts of drum. Check thrust bearings and races for wear or damage. Use petroleum jelly to secure parts in place. Clutch discs should be soaked in ATF for at least 15 minutes before installation.


NOTE: For thrust bearing and race locations, refer to illustration. See **Fig. 71** . For component dimensions, see **THRUST BEARING & RACE SPECIFICATIONS** table.

1. Install oil deflector with 3 bolts to transaxle housing. Install apply pipe and clamp. See **Fig. 7** . Install bolt and tighten to 87 INCH lbs. (9.8 N.m). Ensure pipe is installed to stopper. Install oil seal ring to transaxle housing. See **Fig. 23** . Using appropriate adapter and press, install underdrive cylindrical roller bearing into transaxle housing. DO NOT apply excessive pressure to bearing.

2. Using vernier calipers, measure underdrive brake piston return spring free length with spring mounted to spring seat. Free length should be .521" (13.24 mm). Replace springs as necessary. Install 2 oil seal rings to transaxle case. See **Fig. 16**.
3. For needle roller bearing installation, wrap vinyl tape around bearing installer at a position .157" (4.00 mm) above bottom end of installer, until thickness of tape is about .197" (5.00 mm). Using bearing installer and press, install needle roller bearing to transaxle case until wound vinyl tape contacts transaxle case.
4. Coat 2 NEW "O" rings with ATF and install on underdrive brake piston. See **Fig. 16**. Using hand pressure, install piston into transaxle case. Using appropriate adapter and press, compress underdrive brake piston return springs into transaxle case and install snap ring. DO NOT apply excessive force.
5. Install snap ring into transaxle case. Using appropriate bearing race adapter and press, install 2 bearing outer races into transaxle case. Press each outer race into transaxle case until race contacts snap ring. See **Fig. 15**. Using appropriate adapter and press, install tapered roller bearing to counter drive gear until bearing contacts gear. DO NOT apply excessive force.
6. Using appropriate adapter and press, install counter drive gear and bearing into transaxle case. DO NOT apply excessive pressure. Using vernier calipers, measure 1st/reverse brake piston return spring free length with spring mounted to spring seat. Free length should be .693" (17.61 mm). Replace springs as necessary.

NOTE: In the following step, stop press when piston return spring seat is lowered .039-.079" (1.00-2.00 mm) from snap ring groove. This prevents spring seat from becoming deformed. DO NOT expand snap ring excessively.

7. Coat 2 NEW "O" rings with ATF and install on 1st/reverse brake piston. Using hand pressure, install piston into transaxle case. See **Fig. 15**. Using appropriate adapter and press, compress 1st/reverse brake piston return springs into transaxle case and install snap ring. DO NOT apply excessive force.
8. Install front planetary ring gear and snap ring to brake hub. Install front planetary gear to brake hub. Using appropriate adapter and press, install brake hub with front planetary gear into transaxle case. See **Fig. 56**. Install washer on counter drive gear in correct direction. See **Fig. 57**.
9. Using holding tool, socket and torque wrench, install nut and tighten to 207 ft. lbs. (280 N.m). Using socket, adapter and INCH-lb. torque wrench, measure counter drive gear tapered roller bearing starting torque. Starting torque should be 4.4-9.0 INCH lbs. (.5-1.0 N.m). See **Fig. 58**. If starting torque is not within specification, gradually tighten nut until starting torque is within specification. Stake lock washer to nut.
10. Install 2 thrust bearings, bearing race and front planetary sun gear to front planetary gear. Coat bearing race with ATF and install race to rear planetary gear. Install thrust washer No. 2. Install rear planetary gear into transaxle case. Install snap ring.



G00011294

Fig. 56: Installing Front Planetary Gear With Brake Hub Into Transaxle Case
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.





Fig. 57: Installing Counter Drive Gear Washer
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011296

Fig. 58: Measuring Counter Drive Gear Bearing Starting Torque
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

11. Install 1st/reverse brake. Install 5 plates and 5 discs, starting with a plate and alternating with a disc. DO NOT install flange. Measure 1st/reverse brake piston stroke. Using vernier calipers, measure distance between disc surface and contact surface of 2nd brake assembly at transaxle case. See **Fig. 59** .
12. Piston stroke should be .043-.049" (1.10-1.24 mm). Select appropriate flange to ensure piston stroke is within specification. Flanges are marked in numeric order and are available in thicknesses from .071" (1.80 mm), marked with the number "1", to .098" (2.50 mm), marked with the number "8", in increments of .004" (.10 mm). Recheck piston stroke after flange is installed.





Fig. 59: Measuring 1st/Reverse Brake Piston Stroke
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

13. Install 2nd brake assembly into transaxle case. Install snap ring and measure inside diameter. Snap ring inside diameter should be more than 6.57" (167.0 mm). Snap ring has a specific tapered installation direction. If inside diameter is not within specification, ensure snap ring is installed in correct direction. If snap ring is installed correctly, replace snap ring.
14. Install one-way clutch outer sleeve to 2nd brake assembly. Ensure sleeve is positioned correctly. Install one-way clutch inner race to No. 1 one-way clutch. Ensure inner race is installed correctly. Check No. 1 one-way clutch operating direction. One-way clutch should rotate in counterclockwise direction and lock in clockwise direction. See **Fig. 60**.



G00011310

Fig. 60: Checking No. 1 One-Way Clutch Rotation

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

15. Install No. 1 one-way clutch and thrust bearing into outer sleeve. Ensure Black race on thrust bearing is visible upon installation. Coat thrust washer No. 1 with petroleum jelly and install on rear planetary sun gear. Coat thrust bearing with petroleum jelly and install on rear planetary sun gear. Install rear planetary sun gear onto rear planetary gear.
16. Install 2nd brake. Install 4 discs and 4 plates, starting with a plate and alternating with a disc. DO NOT install flange at this time. Temporarily install snap ring. Using vernier calipers, measure 2nd brake piston stroke between disc surface and snap ring surface. See **Fig. 61** . Piston stroke should be .024-.029" (.62-.74 mm).





Fig. 61: Measuring 2nd Brake Piston Stroke

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

17. Select appropriate flange to ensure piston stroke is within specification. Use the following formula to determine flange thickness: measured distance, minus flange thickness, minus snap ring thickness of .063" (1.60 mm). Flanges are available in thicknesses from .118" (3.00 mm) to .142" (3.60 mm) in increments of .004" (.10 mm), and are marked in numeric order from "1" to "7". Remove snap ring, install appropriate flange and reinstall snap ring. Ensure snap ring end gap is visible through groove in transaxle case.
18. Install bearing race over shaft and onto direct clutch. Install direct clutch assembly and thrust bearing onto rear planetary sun gear assembly. See **Fig. 15** . Ensure discs in direct clutch completely mate with rear planetary sun gear to ensure rear cover can be installed correctly.
19. Ensure transaxle case and rear cover mating surfaces are clean. Place a straightedge onto direct clutch drum. Using vernier calipers, measure distance between bottom of straightedge and transaxle case (dimension "B"). See **Fig. 62** .



G00011299

Fig. 62: Measuring Direct Clutch End Play (Dimension "B")

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

20. Measure dimension No. 1 and dimension No. 2 of rear cover in 2 places. See **Fig. 63** . Subtract dimension No. 2 from dimension No. 1. This total equals dimension "C". Calculate direct clutch end play by subtracting dimension "B" from dimension "C". End play should be .008-.035" (.20-.90 mm).
21. Select a thrust bearing to ensure end play is within specification. Thrust bearings are available in 2 thicknesses of .140" (3.55 mm) with an outside diameter of 2.74" (69.6 mm), and .152" (3.85 mm) with an outside diameter of 2.76" (70.18 mm). Inside diameter of both thrust bearings is 2.11" (53.6 mm). During installation, ensure Black race side of thrust bearing is facing transaxle rear cover.





Fig. 63: Measuring Distance Between Rear Cover Surfaces (Dimensions No. 1 & No. 2)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


22. Install 2 NEW apply gaskets to transaxle case. Install clamp to apply pipes prior to installing pipes to transaxle case. This will prevent apply pipes from being deformed or damaged. Install 2 apply pipes, clamp and bolt. See **Fig. 16** . Ensure pipes are securely inserted into transaxle case until they reach the pipe stopper on pipe. Tighten bolt to 48 INCH lbs. (5.4 N.m).
23. Install needle roller bearing onto transaxle rear cover with inscribed mark on bearing facing up. Using appropriate adapter and press, install needle roller bearing to transaxle rear cover. Press bearing in to a depth of .474-.502" (12.05-12.75 mm). Coat 2 oil seal rings with ATF and install on transaxle rear cover. See **Fig. 15** .
24. Install underdrive brake. Install 3 discs and 3 plates, starting with a plate and alternating with a disc. DO NOT install flange at this time. Temporarily install snap ring. Using a dial indicator, measure underdrive brake piston stroke by applying and releasing 57 psi (4 kg/cm₂) of compressed air to transaxle case. See **Fig. 22** and **Fig. 64** .
25. Piston stroke should be .074-.082" (1.87-2.08 mm). Select appropriate flange to ensure piston stroke is within specification. Flanges are available in 3 thicknesses of .118" (3.00 mm), .126" (3.20 mm) and .134" (3.40 mm), and are marked in numeric order from "1" to "3". Remove snap ring, install appropriate flange and reinstall snap ring.



G00011301

Fig. 64: Measuring Underdrive Brake Piston Stroke
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

26. Ensure transaxle case and rear cover surfaces are clean. DO NOT allow oil to contact surfaces. Coat needle roller bearing with ATF. Apply Three Bond (1281) or equivalent gasket sealant to rear cover around inside edges of bolt holes. Install rear cover onto transaxle case. Install 11 bolts and tighten all bolts except bolt at 5 o'clock position to 18 ft. lbs. (24 N.m). Tighten bolt at 5 o'clock position to 14 ft. lbs. (19 N.m).
27. Install outer race retainer to No. 2 one-way clutch, ensuring long finger of retainer is facing up. See **Fig. 18** . Install underdrive clutch to No. 2 one-way clutch. Rotate underdrive clutch to ensure correct installation. Underdrive clutch should rotate in a counterclockwise direction, and lock in a clockwise direction. See **Fig. 65** .



G00011302

Fig. 65: Checking Underdrive Clutch Assembly Rotation
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

28. Install No. 2 one-way clutch into transaxle case. Note position of index marks on No. 2 one-way clutch. Ensure marks are facing up. See **Fig. 66** . Install snap ring into transaxle case. Coat thrust bearing and bearing race with petroleum jelly and install onto underdrive clutch. Install underdrive clutch into transaxle case.





Fig. 66: Installing No. 2 One-Way Clutch & Retainer

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


29. Install pawl pin and spring to parking lock pawl. Temporarily install parking lock pawl, shaft and spring to transaxle case. See **Fig. 16** . Install underdrive planetary gear assembly into transaxle case. Engage all clutch discs and hub spline of planetary gear assembly firmly and securely. Install parking lock pawl shaft. Install lock pawl clamp and bolt. Tighten bolt to 87 INCH lbs. (9.8 N.m).
30. Using vernier calipers and a straightedge, measure gap between top of differential drive pinion in underdrive planetary gear, and contact surface of transaxle case. See **Fig. 67** . Record measurement as dimension "D".
31. Measure dimension No. 1 and dimension No. 2 of transaxle housing in 2 places. See **Fig. 68** . Subtract dimension No. 2 from dimension No. 1. Record measurement as dimension "E". Install bearing race onto counter drive gear in correct direction. See **Fig. 15** .



G00011304

Fig. 67: Measuring Gap Between Top Of Differential Drive Pinion & Transaxle Case (Dimension "D")

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.




G00011305

Fig. 68: Measuring Distance Between Transaxle Housing Surfaces (Dimensions No. 1 & No. 2)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

32. Coat needle roller bearing with petroleum jelly and install onto multiple clutch hub (shaft side). Install multiple clutch hub into transaxle case. Install thrust bearing onto multiple clutch hub (forward clutch side). Install forward clutch onto multiple clutch hub. See **Fig. 15** . Align splines of all discs of forward clutch with multiple clutch hub. Install thrust bearing onto forward clutch. Ensure Black side of thrust bearing is visible.
33. Install 2 NEW apply gaskets to front of transaxle case. See **Fig. 15** . Install differential assembly. Calculate transaxle housing-to-underdrive planetary gear assembly end play using the following formula: subtract dimension "D" from dimension "E", performed in steps 30 and 31 , minus thrust bearing thickness of .129" (3.28 mm), equals bearing race thickness. End play should be .008-.027" (.20-.69 mm).
34. Select a bearing race to ensure end play is within specification. If dimension "E" minus dimension "D" is less than .292" (7.42 mm), bearing race thickness should be .138" (3.50 mm). If dimension "E" minus dimension "D" is .292" (7.42 mm) or more, bearing race thickness should be .150" (3.80 mm).
35. Install appropriate bearing race onto underdrive planetary gear assembly to ensure end play is within specification. Bearing race outside diameter is 3.268" (83.00 mm). Bearing race inside diameter is 2.220" (56.40 mm). Install appropriate thrust bearing onto bearing race. Thrust bearing outside diameter is 3.345" (84.96 mm). Thrust bearing inside diameter is 2.252" (57.20 mm).
36. Coat oil pump "O" ring with ATF. Install oil pump and 7 bolts. Tighten bolts to 16 ft. lbs. (22 N.m). Ensure transaxle case and transaxle housing surfaces are clean. DO NOT allow oil to contact surfaces. Apply Three Bond (1281) or equivalent gasket sealant about .047" (1.20 mm) wide, to transaxle case around inside edges of bolt holes. Install transaxle housing to transaxle case.
37. Install 16 transaxle housing bolts. Apply thread sealant to 5 lower bolts inside torque converter housing, and tighten these bolts to 16 ft. lbs. (22 N.m) within 10 minutes of installation. Tighten all other bolts to 22 ft. lbs. (29 N.m). Ensure bolts are in correct locations. Longest bolts go inside torque converter housing. See **Fig. 14** .
38. Inspect input shaft end play. Using a dial indicator, measure input shaft end play. See **Fig. 13** . End play should be .011-.049" (.27-1.24 mm). Recheck differential side bearing preload. Using appropriate adapter and INCH-lb. torque wrench, measure differential preload. See **Fig. 55** . Preload should be 9.0-14.0 INCH lbs. (1.0-1.6 N.m) for NEW bearings and 4.4-7.1 INCH lbs. (.5-.8 N.m) for used bearings.
39. If preload is not within specification, remove differential assembly from transaxle case and replace shim at rear tapered roller bearing. See **Fig. 53** .
40. Place transaxle on 2 blocks of wood, with oil pan surface facing outward. Coat NEW manual valve lever shaft oil seal with ATF. Install oil seal into transaxle case. Install parking lock pawl rod to manual valve lever. Install NEW spacer and manual valve lever shaft into transaxle case. See **Fig. 7** .
41. Using a pin punch and hammer, drive in NEW roll pin. Turn spacer and lever shaft to align small hole for locating staking position in spacer with position mark on lever shaft. Using a pin punch and hammer, stake spacer through small hole. Ensure spacer does not turn.
42. Using needle nose pliers, install retainer spring. Install parking lock pawl bracket. Install bolts and tighten to 15 ft. lbs. (20 N.m). Install cover, manual detent spring and 2 bolts. Ensure cover and detent spring are installed correctly. See **Fig. 7** .
43. Tighten 1.063" (27.00 mm) bottom bolt to 15 ft. lbs. (20 N.m). Tighten .630" (16.00 mm) top bolt to 106 INCH lbs. (12 N.m). Coat NEW "O" rings with ATF and install them onto accumulator pistons. Coat 4 springs and 3 accumulator pistons with ATF, and install components into transaxle case holes. See **Fig.**

69 . See **ACCUMULATOR SPRING FREE LENGTH SPECIFICATIONS** table for spring specifications and identification.



G00011306

Fig. 69: Identifying Accumulator Piston & Spring Locations
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ACCUMULATOR SPRING FREE LENGTH SPECIFICATIONS


Application (Color)	Free Length - In. (mm)	Outer Diameter - In. (mm)
Forward Clutch (Red)	3.564 (90.53)	.728 (18.50)
Underdrive Brake		
Inner	2.372 (60.24)	.626 (15.90)

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul


(Green)		
Outer (Blue)	2.859 (72.61)	.657 (16.70)
Underdrive Clutch (Yellow)	3.412 (86.66)	.756 (19.20)

44. Install check ball body and spring. See **Fig. 9** . Coat NEW "O" ring with ATF and install on transaxle solenoid connector. Install connector into transaxle case, above park/neutral position switch, and tighten bolt to 48 INCH lbs. (5.4 N.m). Coat NEW apply gaskets with ATF and install them into transaxle case, below valve body assembly. Install brake drum gasket located near apply gaskets. See **Fig. 9** .
45. Install valve body assembly. See **VALVE BODY ASSEMBLY** under ON-VEHICLE SERVICE. Push valve body assembly against accumulator piston springs and check ball body to assist in installation. Coat NEW oil strainer gasket with ATF and install on oil strainer. Install oil strainer and tighten bolts to 97 INCH lbs. (11 N.m).
46. Connect 5 shift solenoid connectors. Install fluid temperature sensor, clamps and bolt. Tighten bolt to 58 INCH lbs. (6.6 N.m). See **Fig. 8** . Install 3 magnets into oil pan in original locations. Apply Three Bond (2430) or equivalent to 18 oil pan bolt threads. Install NEW oil pan gasket, oil pan and bolts. Tighten bolts to 69 INCH lbs. (7.8 N.m) within 10 minutes of installation.
47. Coat NEW "O" rings with ATF and install on speed sensors. Install input turbine and counter gear speed sensors into top of transaxle case. Tighten bolts to 97 INCH lbs. (11 N.m). Install NEW "O" rings on oil line union and elbow (if equipped). Install oil line union and elbow into transaxle case. Tighten to 20 ft. lbs. (27 N.m).
48. Coat NEW "O" ring with ATF and install on transaxle test plug. Install transaxle test plug into transaxle case. See **Fig. 3** . Install park/neutral position switch onto manual valve lever shaft and temporarily install 2 adjusting bolts. See **Fig. 7** .
49. Install NEW lock tab and nut. Tighten nut to 61 INCH lbs. (6.9 N.m). Temporarily install control shift lever. Turn lever counterclockwise until it stops, then turn it clockwise 2 notches. Remove control shift lever. Align groove in park/neutral position switch to neutral basic line. Tighten 2 adjusting bolts to 48 INCH lbs. (5.4 N.m). Stake lock tab onto nut. Install control shift lever, washer and nut. Tighten nut to 61 INCH lbs. (6.9 N.m).
50. Install torque converter into transaxle housing while rotating. Ensure converter is properly installed by measuring distance from edge of transaxle housing. See **Fig. 70** . Distance should be .524" (13.30 mm) for all models.



G95J19280

Fig. 70: Measuring Torque Converter Depth
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.



G00011307

Fig. 71: Identifying Thrust Bearing & Race Locations
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

THRUST BEARING & RACE SPECIFICATIONS ⁽¹⁾

--	--	--

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

Application	Inner Diameter - In. (mm)	Outer Diameter - In. (mm)
A		
Bearing	2.252 (57.20)	3.345 (84.96)
Rear Race	2.220 (56.40)	3.268 (83.00)
B		
Bearing	1.485 (37.73)	2.283 (58.00)
Rear Race	1.177 (29.90)	2.185 (55.50)
C		
Bearing	1.333 (33.85)	2.055 (52.20)
D		
Bearing	.925 (23.50)	1.732 (44.00)
E		
Bearing	1.429 (36.30)	2.055 (52.20)
Rear Race	1.358 (34.50)	1.909 (48.50)
F		
Bearing	1.362 (34.60)	1.909 (48.50)
G		
Front Race	1.587 (40.30)	2.283 (58.00)
Bearing	1.520 (38.60)	2.362 (60.00)
Rear Race	1.520 (38.60)	2.283 (58.00)
H		
Bearing	2.110 (53.60)	2.740 (69.60)
I		
Bearing	1.327 (33.70)	1.898 (48.20)
Rear Race	1.193 (30.30)	1.811 (46.00)
J		
Bearing	2.110 (53.60)	2.740 (69.60) Or 2.763 (70.18)
(1) For component locations, refer to illustration. See Fig. 71 .		

TORQUE SPECIFICATIONS

TORQUE SPECIFICATIONS

Application	Ft. Lbs. (N.m)

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

Converter-To-Drive Plate Bolt	30 (41)
Counter Drive Gear Nut	207 (280)
Differential Ring Gear Bolt	71 (96)
Drive Plate Bolt	65 (88)
Elbow	20 (27)
Manual Detent Spring Bottom Bolt	15 (20)
Oil Pan Drain Plug	36 (49)
Oil Pump Bolt	16 (22)
Parking Lock Pawl Bracket Bolt	15 (20)
Transaxle Housing-To-Transaxle Case Bolt	
Lower Bolts (5)	16 (22)
All Other Bolts	22 (29)
Transaxle Rear Cover Bolt	
Bolt At 5 O'Clock Position	14 (19)
All Other Bolts	18 (25)
Underdrive Planetary Gear Lock Nut	207 (280)
Union	20 (27)
INCH Lbs. (N.m)	
Apply Pipe Clamp Bolt	
Transaxle Case	48 (5.4)
Transaxle Housing	87 (9.8)
Control Shift Lever Lock Tab Nut	61 (6.9)
Manual Detent Spring Top Bolt	106 (12)
Oil Deflector Bolt	87 (9.8)
Oil Pan Bolt	69 (7.8)
Oil Strainer Bolt	97 (11)
Parking Lock Pawl Clamp Bolt	87 (9.8)
Park/Neutral Position Switch	
Nut	61 (6.9)
Bolt	48 (5.4)
Pressure Relief Check Ball Retainer Bolt	97 (11)
Shift Solenoids	
SLT & SL1 Solenoid Bolt	58 (6.6)
All Other Solenoid Bolts	97 (11)
Solenoid Connector Bolt	48 (5.4)
Speed Sensor Bolt	11 (97)
Stator Shaft-To-Oil Pump Bolt	87 (9.8)
Temperature Sensor Clamp Bolt	58 (6.6)
Upper Valve Body Cover Bolt	58 (6.6)
Upper & Lower Valve Body Bolt	97 (11)
Valve Body-To-Transaxle Bolt	97 (11)

2000 Toyota Celica GT

2000 AUTOMATIC TRANSMISSIONS Toyota U240E Overhaul

CLUTCH DISC & PLATE SPECIFICATIONS**CLUTCH DISC & PLATE QUANTITY**

Component	Discs	Plates
Direct Clutch	4	4
Forward Clutch	4	4
Underdrive Brake	3	3
Underdrive Clutch	3	3
1st/Reverse Brake	5	5
2nd Brake	4	4

TRANSAXLE SPECIFICATIONS**TRANSAXLE SPECIFICATIONS**

Application	In. (mm)
Bushing Inside Diameter (Maximum)	
Multiple Clutch Hub	.909 (23.09)
Oil Pump Body	1.503 (38.18)
Oil Pump Stator Shaft	.849 (21.57)
Underdrive Clutch Drum	1.285 (32.64)
Direct Clutch End Play	.008-.035 (.20-.90)
Input Shaft End Play	.011-.049 (.27-1.24)
Underdrive Planetary Gear Assembly End Play	.008-.027 (.20-.69)
Oil Pump	
Driven Gear-To-Body Clearance	.003-.006 (.07-.15)
Driven Gear Tip-To-Crescent Clearance	.004-.006 (.11-.15)
Gear Side Clearance	.0008-.0016 (.020-.040)
Piston Stroke	
Direct Clutch	.024-.029 (.62-.74)
Forward Clutch	.025-.041 (.63-1.04)
Underdrive Brake	.074-.082 (1.87-2.08)
Underdrive Clutch	.058-.067 (1.47-1.69)
1st/Reverse Brake	.043-.049 (1.10-1.24)
2nd Brake	.024-.029 (.62-.74)
Side Gear Backlash	.002-.008 (.05-.20)
Torque Converter Runout (Maximum)	
Drive Plate	.008 (.20)
Sleeve	.012 (.30)
Torque Converter Installed Depth	.524 (13.30)