


## FUEL TANK AND LINE COMPONENTS

SF0F8-03

**CAUTION:**

- Always use new gaskets when replacing the fuel tank or components part.
- Apply the proper torque to all parts tightened.



$\vee$  N·m (kgf·cm, ft·lbf) : Specified torque    ◆ Non-reusable part

B10372