


AIR CONDITIONING AMPLIFIER (Electrical Multi Vision) REMOVAL

ACOPM-01

1. REMOVE A/C CONTROL ASSEMBLY
(See page [AC-95](#))

2. REMOVE A/C AMPLIFIER

Remove the 8 bolts 2 screws and 2 bracket, then remove the amplifier.



I02319