


# OIL W/HOSE COOLER ASSY (U241E/U140F)


4017J-01

## REPLACEMENT

1. **REMOVE RADIATOR GRILLE** (See page 76-2 )
2. **REMOVE FRONT BUMPER COVER** (See page 76-2 )
3. **SEPARATE OIL COOLER OUTLET TUBE NO.1**
  - (a) Loosen the clip and separate the oil cooler hose.
4. **SEPARATE TRANSMISSION OIL COOLER HOSE NO.1**
  - (a) Loosen the clip and separate the transmission oil cooler hose No. 1.



5. **REMOVE OIL W/HOSE COOLER ASSY**
  - (a) Remove the bolt, nut and oil cooler assy.



6. **INSTALL OIL W/HOSE COOLER ASSY**
  - (a) Install the oil cooler assy, bolt A and nut B.

**HINT:**  
After temporally tightening bolt A, tighten in order of nut B, bolt A.

**Torque: 7.0 N·m (71 kgf·cm, 62 in.-lbf)**

7. **INSTALL TRANSMISSION OIL COOLER HOSE NO.1**
  - (a) Install the transmission oil cooler hose No. 1 and clip.
8. **INSTALL OIL COOLER OUTLET TUBE NO.1**
  - (a) Install the oil cooler hose and clip.
9. **ADD AUTOMATIC TRANSAXLE FLUID**
10. **INSPECT AUTOMATIC TRANSAXLE FLUID** (See page 40-2 )