


# HEADLAMP DIMMER SWITCH ASSY REPLACEMENT

6512J-01

**HINT:**

Installation is in the reverse order of removal.

1. **REMOVE STEERING COLUMN COVER LWR (SEE PAGE 50-8 )**
2. **REMOVE STEERING COLUMN COVER UPR (SEE PAGE 50-8 )**

**3. REMOVE HEADLAMP DIMMER SWITCH ASSY**

- (a) Disconnect the connector.
- (b) Using a screwdriver, disengage the claw, and remove the headlamp dimmer switch assy.

**NOTICE:**

**Pressing the claw hard breaks the claw.**

**HINT:**

Tape the screwdriver tip before use.