

PROBLEM SYMPTOMS TABLE

1. TROUBLESHOOTING FOR EACH PROBLEM SYMPTOM

NOTICE:

Confirm the problem symptom and make an inspection depending on the applicable flow chart.

Problem Symptom	Suspected Area	See Page
B1211/11 (no communication from driver door ECU for more than 10 seconds)	1. Power window regulator master switch assembly 2. Wire harness	05-2051 05-2051
B1214 (short in communication circuit and +B power source system)	1. Power window regulator master switch assembly 2. ECM 3. Air conditioning amplifier assembly 4. Combination meter assembly 5. Theft warning ECU 6. Sliding roof drive gear 7. Wire harness 8. MPX body ECU	05-2056 05-2056 05-2056 05-2056 05-2056 05-2056 05-2056 05-2056
B1215 (short in communication circuit and body ground)	1. Power window regulator master switch assembly 2. ECM 3. Air conditioning amplifier assembly 4. Combination meter assembly 5. Theft warning ECU 6. Sliding roof drive gear 7. Wire harness 8. MPX body ECU	05-2056 05-2056 05-2056 05-2056 05-2056 05-2056 05-2056 05-2056
B1261 (no communication from ECM for more than 10 seconds)	1. ECM 2. Wire harness	05-2065 05-2065
B1262/62 (no communication from A/C ECU for more than 10 seconds)	1. Air conditioning amplifier assembly 2. Wire harness	05-2070 05-2070
B1269/69 (no communication from theft deterrent ECU for more than 10 seconds)	1. Theft warning ECU 2. Wire harness	05-2075 05-2075
B1271 (no communication from combination meter ECU for more than 10 seconds)	1. Combination meter assembly 2. Wire harness	05-2080 05-2080
B1273/73 (no communication from sliding roof control ECU for more than 10 seconds)	1. Sliding roof drive gear 2. Wire harness	05-2085 05-2085