


# REAR COMBINATION LAMP ASSY LH

## OVERHAUL

6512G-01

**HINT:**

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- Installation is in the reverse order of removal.

**1. REMOVE REAR COMBINATION LAMP SERVICE COVER LH****2. REMOVE REAR COMBINATION LAMP ASSY LH**

- (a) Disconnect the connector.
- (b) Remove the 2 nuts and the rear combination lamp assy LH.

**3. REMOVE REAR COMBINATION LAMP LENS GASKET RH****4. REMOVE REAR COMBINATION LAMP BULB**

- (a) Remove the rear combination lamp bulb and the socket and wire.
- (b) Remove the rear combination lamp bulb from the socket and wire.

**5. REMOVE REAR COMBINATION LAMP SOCKET AND WIRE SUB-ASSY LH****6. REMOVE REAR COMBINATION LAMP LENS LH**