







Service Hints

TAILLIGHT Relay

5-3 : Closed with the light control SW at TAIL or HEAD position

C13 Combination SW

14-16 : Closed with the light control SW at TAIL or HEAD position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A10	42	E4	42	R3	B 43
A22	42	F7	38 (3MZ-FE)	R4	43
B9	A 42		40 (2AZ-FE)	R23	43
B10	B 42	G4	43	R24	43
C10	42	J19	44	R26	45
C11	42	M2	43	S3	43
C13	42	M3	43	S4	43
C16	42	R2	A 43	T16	43

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	29	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
1D	29	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1J	28	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
1K		
2A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3A	30	Instrument Panel Wire and Center J/B (Behind the Instrument Panel Center)
3B		
3D		
3E		
3F		
3G	31	
3H		
3I		
3J		
3K		
4D	33	Cowl Wire and Passenger Side J/B (Right Side of Grove Box)
4H		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK3	54	Engine Room Main Wire and Cowl Wire (Right Cowl Side Panel)
IL2	54	Instrument Panel Wire and Cowl Wire (Upper Side of Passenger Side J/B)
IR1	54	Instrument Panel Wire and Floor Wire (Under the Shift Lever)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IA	52	Left Cowl Side Panel
IB	52	Right Instrument Panel Brace
BB	56	Right Center Pillar
BF	56	Near the Rear Side Marker Light RH

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I2	54	Instrument Panel Wire			