


AMP SOUND SIGNAL CIRCUIT (RADIO RECEIVER ASSY - AMP)

CIRCUIT DESCRIPTION

The radio receiver assy sends a sound signal to the stereo component amplifier assy through this circuit. The sound signal that has been sent is amplified by the stereo component amplifier assy, and then is sent to the speaker.


If there is an open or short in the circuit, sound can not be heard from the speaker even if there is no malfunction in the stereo component amplifier assy or speaker.

WIRING DIAGRAM



INSPECTION PROCEDURE


| | |
|---|---|
| 1 | CHECK HARNESS AND CONNECTOR(RADIO RECEIVER ASSY - STEREO COMPONENT AMPLIFIER ASSY) |
|---|---|

Radio Receiver Assy:

- (a) Disconnect the connectors from the radio receiver assy and stereo component amplifier assy.
- (b) Measure the resistance according to the values in the table below.

Standard:

| Tester connection | Specified condition |
|-------------------|-------------------------|
| FL+ - F.L | Below 1 Ω |
| FR+ - F.R | Below 1 Ω |
| RL+ - R.L | Below 1 Ω |
| RR+ - R.R | Below 1 Ω |
| FL+ - Body ground | 10 k Ω or higher |
| FR+ - Body ground | 10 k Ω or higher |
| RL+ - Body ground | 10 k Ω or higher |
| RR+ - Body ground | 10 k Ω or higher |

Stereo Component Amplifier Assy:**NG****REPAIR OR REPLACE HARNESS OR CONNECTOR****OK**

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1632)