

# SPEED SENSOR FRONT LH REPLACEMENT


3215T-01

## HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.


### 1. REMOVE FRONT WHEEL

### 2. REMOVE FRONT FENDER SPLASH SHIELD SUB-ASSY LH




### 3. REMOVE SPEED SENSOR FRONT LH

- (a) Disconnect the speed sensor connector.




- (b) Remove the 2 bolts and the clamp from the body and the shock absorber assy.



- (c) Remove the bolt and the speed sensor front.

## NOTICE:

Prevent foreign matter from attaching to the sensor tip.




### 4. INSTALL SPEED SENSOR FRONT LH

- (a) Install the speed sensor front with the bolt.

**Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)**

## NOTICE:

Prevent foreign matter from attaching to the sensor tip.



- (b) Install the speed sensor front with the 2 bolts and the clamp.


**Torque:**

**Bolt A: 5.0 N·m (51 kgf·cm, 44 in·lbf)**

**Bolt B: 19 N·m (192 kgf·cm, 14 ft·lbf)**

**NOTICE:**

**Do not twist the sensor wire when installing the sensor.**



- (c) Connect the speed sensor connector.

5. **INSTALL FRONT FENDER SPLASH SHIELD SUB-ASSY LH**
6. **INSTALL FRONT WHEEL**  
**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**
7. **CHECK ABS SPEED SENSOR SIGNAL (SEE PAGE [05-765](#) )**