


## TS AND CG TERMINAL CIRCUIT

### CIRCUIT DESCRIPTION

In the sensor check mode, a malfunction of the speed sensor that cannot be detected when the vehicle is stopped is detected while driving.


Transition to the sensor check mode can be performed by connecting terminals TS and CG of the DLC3 and turning the ignition switch from off to the ON position.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

#### 1 INSPECT DLC3 TERMINAL VOLTAGE(TS TERMINAL)



- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

#### Standard:

Tester Connection	Specified Condition
D3-12 (TS) - D3-4 (CG)	10 to 14 V

NG


Go to step 3

OK


## 2 CHECK HARNESS AND CONNECTOR(DLC3 - BODY GROUND)

Skid Control ECU

(harness side connector) (S27)



TS

(D3)  
DLC3G24767  
C52361

I37493

- (a) Disconnect the skid control ECU connector.  
(b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
S27-24 (TS) - D3-12 (TS)	Below 1 $\Omega$

- (c) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
S27-24 (TS) - Body ground	10 k $\Omega$ or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR


OK

REPLACE ABS &amp; TRACTION ACTUATOR ASSY (SEE PAGE 32-37 )

## 3 CHECK HARNESS AND CONNECTOR(BODY GROUND - DLC3)

DLC3

(D3)



CG

C52361

- (a) Measure the resistance according to the value(s) in the table below.

**Standard:**


Tester Connection	Specified Condition
D3-4 (CG) - Body ground	Below 1 $\Omega$

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK HARNESS AND CONNECTOR(SKID CONTROL ECU - DLC3)



- (a) Disconnect the skid control ECU connector.  
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
S27-24 (TS) - D3-12 (TS)	Below 1 $\Omega$

- (c) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
S27-24 (TS) - Body ground	10 k $\Omega$ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE ABS & TRACTION ACTUATOR ASSY (SEE PAGE 32-37 )