

ABS WITH EBD & BA & TRAC & VSC SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

05CCW-06

The hand-held tester can be used at step 3, 6, 9, 12.


1	Vehicle Brought to Workshop
----------	------------------------------------




2	Customer Problem Analysis (SEE PAGE 05-763)
----------	---




3	Check and Clear DTCs and Freeze Frame Data (SEE PAGE 05-765)
----------	--



4	Problem Symptom Confirmation
----------	-------------------------------------



Symptom does not occurs: Go to step 5
--




Symptom occurs: Go to step 6


5	Symptom Simulation (SEE PAGE 01-36)
----------	---



6	DTC Check (SEE PAGE 05-765)
----------	---




There is no output: Go to step 7



There is output: Go to step 8

7	Problem Symptoms Table (SEE PAGE 05-786)
----------	--



Check for fluid leakage and Go to step 10
--

8	DTC Chart (SEE PAGE 05-779)
----------	---



9	Circuit Inspection (SEE PAGE 05-788 to 05-873)
----------	--



10	Identification of Problem
-----------	----------------------------------



11	Repair
----	--------



12	Confirmation Test
----	-------------------



End
