

## REPLACEMENT

### HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- Installation is in the reverse order of removal.


1. **PRECAUTION (SEE PAGE 60-1 )**
2. **DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1 )**
3. **REMOVE ROOF HEADLINING ASSY (SEE PAGE 76-21 )**
4. **REMOVE CURTAIN SHIELD AIR BAG ASSY LH**

- (a) Disconnect the connector from the curtain shield airbag assy LH.

### NOTICE:

**When handling the airbag connector, take care not to damage the airbag wire harness.**

- (b) Remove the 3 clips.
- (c) Remove the 9 bolts and the curtain shield airbag assy LH in the order shown in the illustration.



**5. INSPECT CURTAIN SHIELD AIR BAG ASSY LH (SEE PAGE 60-11)****6. INSTALL CURTAIN SHIELD AIR BAG ASSY LH**


- (a) Install the curtain shield airbag assy LH with the 9 bolts in the order shown in the illustration.
- (b) Install the 3 clips.

**Torque: 14 N·m (143 kgf·cm, 10 ft·lbf)**

- (c) Connect the connector to the curtain shield airbag assy LH.

**NOTICE:**

**When handling the airbag connector, take care not to damage the airbag wire harness.**

**7. INSTALL ROOF HEADLINING ASSY (SEE PAGE 76-21)****8. CONNECT BATTERY NEGATIVE TERMINAL****9. INSPECT SRS WARNING LIGHT (SEE PAGE 05-1207)**