


# POWER POINT SOCKET ASSY RR REPLACEMENT

67169-01

## HINT:

- COMPONENTS: See page 67-2
- Installation is in the reverse order of removal.




## 1. REMOVE POWER POINT SOCKET ASSY RR

- Using a screwdriver, disengage the claw on the power point socket cover from the hole in the power point socket, then pull out the power point socket approx. 10 mm (0.39 in.).

## HINT:

Tape the screwdriver tip before use.




- Using a screwdriver, disengage the claw on the power point socket cover from the body and remove the power point socket and cover as a unit.

## HINT:

Tape the screwdriver tip before use.

- Disconnect the connector.
- Disassemble the power point socket from the socket cover.



## 2. INSTALL POWER POINT SOCKET ASSY RR

- Assemble the power point socket to the power point socket cover at the position 10 mm (0.39 in.) away from full lock position and ensure that they are temporarily locked.
- Align the cut-out on the body with the claw on the power point socket cover and install the power point socket and cover to the body.
- After installing them, push in the power point socket approx. 10 mm (0.39 in.) to lock it.