

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver's and passenger's seat heaters do not warm up	1. SEAT HTR fuse 2. IG1 fuse 3. Seat heater relay 4. Wire harness	72-66 72-66 72-68 -
Only driver's seat heater does not warm up	1. Seat heater (front) switch LH 2. Front seat cushion Cover LH (seat cushion heater assy LH) 3. Front seatback cover LH (seatback heater assy LH) 4. Wire harness	72-68 72-68 72-68 -
Only passenger's seat heater does not warm up	1. Seat heater (front) switch RH 2. Front seat cushion Cover RH (seat cushion heater assy RH) 3. Front seatback cover RH (seatback heater assy RH) 4. Wire harness	72-68 72-68 72-68 -