

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below (Proceed to the page given for that circuit.).

DTC No. (See Page)	Detection Item	Trouble Area	Open Door Warning Light
B1222/22 (05-1944)	Door lock switch circuit on driver door	<ul style="list-style-type: none"> • Power window regulator master switch assy (door ECU) • Front door lock assy RH (driver side) • Multiplex Network Body ECU 	Blinks
B1223/23 (05-1948)	Power window switch circuit on passenger door	<ul style="list-style-type: none"> • Door control switch assy (passenger side) • Multiplex Network Body Body ECU 	Blinks
B1224/24 (05-1950)	Door lock switch circuit on passenger door	<ul style="list-style-type: none"> • Door control switch assy (passenger side) • Front door lock assy RH (passenger side) • Multiplex Network Body Body ECU 	Blinks