

## SYSTEM DESCRIPTION

### 1. TIRE PRESSURE WARNING SYSTEM DESCRIPTION


- (a) The tire pressure warning system informs the driver if it detects a low tire pressure. When the tire pressure warning system detects low tire pressure in any of the 4 wheels, which affects safe driving the tire pressure warning lamp comes on.

	Specified Value
Front	210 kpa (2.1 kgf/cm <sup>2</sup> , 30 psi)
Rear	210 kpa (2.1 kgf/cm <sup>2</sup> , 30 psi)

- (b) Tire pressure warning system is controlled by the skid control ECU.

**HINT:**

When the tire pressure reset switch is push, the tire pressure warning lamp goes off.



### 2. TIRE PRESSURE WARNING DISPLAY FUNCTION

- (a) The tire pressure warning lamp comes on, according to the condition of the tire pressure warning system, as shown in the DIAGNOSIS SYSTEM (see page [05-744](#) ).