


DIFFERENTIAL OIL (4WD)

ADJUSTMENT

2900Y-05



1. INSPECT DIFFERENTIAL OIL

- (a) Stop the vehicle on the level place.
- (b) Remove the differential filler plug and gasket.
- (c) Check that the oil surface is within 5 mm (0.20 in.) from the lowest position of the inner surface of the differential filler plug opening.

NOTICE:

- **Excessively large or small amount of oil may cause troubles.**
- **After replacing oil, drive the vehicle and check the oil level.**

HINT:

If nesenary, fill the rear differential carrier assy with hypoid gear oil.

Oil grade: Hypoid gear oil API GL-5

Recommended oil viscosity:

Above -18°C (0°F) SAE 90

Below -18°C (0°F) SAE 80W or 80W-90

Capacity: 0.9 ± 0.05 liters (0.95 ± 0.05 US qts, 0.79 ± 0.04 Imp. qts)

- (d) Check for oil leakage when the oil level is low.
- (e) Install the differential filler plug and a new gasket.

Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)