

PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
B1221/21 (Door ECU SW ON)	1. Power window regulator master switch assy (door ECU)	05-1912
B1231/31 (Driver side jam protection limit switch malfunctions)	1. Power window regulator motor assy LH	05-1913
B1232/32 (Driver side jam protection sensor malfunctions)	1. Power window regulator motor assy LH	05-1913
AUTO UP/AUTO DOWN does not operate (only driver side)	1. Power window regulator master switch assy (door ECU) 2. Power window regulator motor assy LH	05-1913 05-1913
Power window operation is impossible by operation interlocked with key (only driver side)	1. Front door lock assy RH 2. Power window regulator master switch assy (door ECU)	05-1957 05-1909
Operation is impossible after key-OFF (only driver side)	1. Front door courtesy lamp switch assy 2. Multiplex network body ECU	05-1957 05-1909
Driver's side power window does not operate	1. P FR DOOR 20 A fuse 2. ECU-B 7.5 A fuse 3. IG1 7.5 A fuse 4. Power window regulator master switch assy (door ECU) 5. Power window regulator motor assy RH 6. Wire harness	05-1915 05-1915 05-1915 05-1915 05-1915 05-1915
Window operation via regulator switch for each seat is impossible	1. P FR DOOR 20 A fuse 2. D FR DOOR 25 A fuse 3. D RR DOOR 20 A fuse 4. P RR DOOR 20 A fuse 5. Power window regulator master switch assy (door ECU) 6. Power window regulator switch assy 7. Power window regulator motor assy RH 8. Power window regulator motor assy LH 9. Wire harness	05-1920 05-1920 05-1920 05-1920 05-1920 05-1920 05-1920 05-1920 05-1920
Remote operation of other seat via master switch is impossible	1. Power window regulator master switch assy (door ECU) 2. Multiplex network body ECU 3. Wire harness	05-1929 05-1929 05-1929