


## REPLACEMENT

### HINT:

Installation is in the reverse order of removal.

1. **PRECAUTION (SEE PAGE 60-1 )**
2. **DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1 )**



### 3. REMOVE STEERING WHEEL COVER LOWER NO.3

- (a) Using a screwdriver, remove the steering wheel cover lower No.3.

### HINT:

Tape up the screwdriver tip before use.

### 4. REMOVE STEERING WHEEL COVER LOWER NO.2

- (a) Using a screwdriver, remove the steering wheel cover lower No.2.

### HINT:

Tape up the screwdriver tip before use.

### 5. REMOVE HORN BUTTON ASSY

- (a) Place the front wheels facing straight ahead.
- (b) Using a torx® socket wrench (T30), loosen the 2 torx® screws until the groove along the screw circumference catches on the screw case.
- (c) Pull out the horn button assy from the steering wheel assy and support the horn button assy with one hand as shown in the illustration.

### NOTICE:



**When removing the horn button assy, do not pull the airbag wire harness.**

- (d) Disconnect the horn connector.
- (e) Disconnect the 2 connectors from the horn button assy.

### NOTICE:

**When handling the airbag connector, take care not to damage the airbag wire harness.**

- (f) Remove the horn button assy.



### 6. INSTALL HORN BUTTON ASSY

- (a) Support the horn button assy with one hand as shown in the illustration.
- (b) Connect the 2 connectors to the horn button assy.

### NOTICE:


**When handling the airbag connector, take care not to damage the airbag wire harness.**

- (c) Connect the horn connector.

- (d) Confirm that the circumference groove of the torx® screw fits in the screw case, and place the horn button assy onto the steering wheel assy.
- (e) Using a torx® socket wrench (T30), tighten the 2 torx® screws.

**Torque: 8.8 N·m (90 kgf·cm, 78 in·lbf)**

## 7. CONNECT BATTERY NEGATIVE TERMINAL



## 8. INSPECT HORN BUTTON ASSY

- (a) With the horn button assy installed on the vehicle, perform a visual check including the following:  
Cuts, minute cracks or marked discoloration on the horn button assy top surface and in the grooved portion.
- (b) Make sure that the horn sounds.

### HINT:

If the horn does not sound, inspect the horn system (see page 69-2 ).

## 9. INSPECT SRS WARNING LIGHT (SEE PAGE 05-1207 )