

SRS WARNING LIGHT CIRCUIT MALFUNCTION (ALWAYS LIGHT UP, WHEN DTC IS NOT OUTPUT.)


CIRCUIT DESCRIPTION

The SRS warning light is located on the combination meter.

When the SRS is normal, the SRS warning light lights up for approx. 6 seconds after the ignition switch is turned from the LOCK position to ON position, and then turns off automatically.

If there is a malfunction in the SRS, the SRS warning light lights up to inform the driver of the abnormality. When terminals Tc and CG of the DLC3 are connected, the DTC is displayed by blinking the SRS warning light.

WIRING DIAGRAM



H45942

INSPECTION PROCEDURE

1 CHECK CONNECTOR

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the airbag sensor assy center and the combination meter assy.

OK:

The connectors are connected.


NG

CONNECT CONNECTORS


OK

2 CHECK WIRE HARNESS

Airbag Sensor Assy Center:



Combination Meter Assy:



H40452

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connector from the airbag sensor assy center.
- (d) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A17-24 (MPX1) - C11-21	Always	Below 1 Ω
A17-24 (MPX1) - A17-22 (MPX2)	Always	1 M Ω or Higher


NG

REPAIR OR REPLACE WIRE HARNESS (AIRBAG SENSOR ASSY CENTER - COMBINATION METER ASSY)

OK

3

CHECK COMBINATION METER ASSY



- (a) Disconnect the connector from the combination meter assy.
- (b) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position.
- (d) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
C11-21 - Body ground	Ignition switch ON	8 to 14 V

NG

REPLACE COMBINATION METER ASSY
(SEE PAGE 71-10)

OK

REPLACE AIR BAG SENSOR ASSY CENTER (SEE PAGE 60-53)