

DTC	B1780	OCCUPANT CLASSIFICATION SENSOR FRONT LH CIRCUIT MALFUNCTION
------------	--------------	--

CIRCUIT DESCRIPTION

The occupant classification sensor front LH circuit consists of the occupant classification ECU and the occupant classification sensor front LH.


DTC B1780 is recorded when a malfunction is detected in the occupant classification sensor front LH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1780	<ul style="list-style-type: none"> When the occupant classification ECU receives a line short signal, open signal, short to ground signal or B+ short signal in the occupant classification sensor front LH circuit for 2 seconds. Occupant classification sensor front LH malfunction Occupant classification ECU malfunction 	<ul style="list-style-type: none"> Seat adjuster frame assy (Occupant classification sensor front LH) Front seat wire RH Occupant classification ECU

HINT:

- When DTC B1150/23 is detected as a result of troubleshooting for the supplemental restraint system, perform troubleshooting for the DTC B1780 of the occupant classification system.
- Use the hand-held tester to check the DTC of the occupant classification ECU, otherwise the DTC cannot be read.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

- If troubleshooting (wire harness inspection) is difficult to perform, remove the front RH seat assy installation bolts to see the under surface of seat cushion.
- In the above case, hold the seat so that it does not fall down. Holding the seat for a long period of time may cause a problem, such as seat rail deformation. Hold the seat only as necessary.

1 CHECK DTC

- (a) Turn the ignition switch to the ON position.
- (b) Clear the DTCs stored in memory (see page 05-1215).

HINT:

- First clear DTCs stored in the occupant classification ECU memory and then in the airbag sensor assy center memory.
 - Use the hand-held tester to clear the DTC of the occupant classification ECU, otherwise the DTC cannot be cleared.
- (c) Turn the ignition switch to the LOCK position.
 - (d) Turn the ignition switch to the ON position.
 - (e) Using the hand-held tester, check the DTCs (see page 05-1215).

OK:

DTC B1780 is not output.

HINT:

Codes other than code B1780 may be output at this time, but they are not related to this check.

NG

Go to step 2

OK

USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1207)

2 CHECK CONNECTION OF CONNECTORS

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the occupant classification ECU and the occupant classification sensor front LH.


OK:

The connectors are connected.

NG

CONNECT CONNECTORS, THEN GO TO STEP 1


OK

3 CHECK FRONT SEAT WIRE RH (TO B+)

- Disconnect the connectors from the occupant classification ECU and the occupant classification sensor front LH.
- Connect the negative (-) terminal cable to the battery.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
O7-1 (SGD1) - Body ground	Ignition switch ON	Below 1 V
O7-7 (SIG1) - Body ground	Ignition switch ON	Below 1 V
O7-11 (SVC1) - Body ground	Ignition switch ON	Below 1 V

NG**REPAIR OR REPLACE FRONT SEAT WIRE RH****OK****4 CHECK FRONT SEAT WIRE RH (OPEN)**

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Using a service wire, connect O8-1 (SVC1) and O8-3 (SGD1), and connect O8-2 (SIG1) and O8-3 (SGD1) of connector "C".

NOTICE:

Do not forcibly insert a service wire into the terminals of the connector when connecting.


- Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
O7-7 (SIG1) - O7-1 (SGD1)	Always	Below 1 Ω
O7-11 (SVC1) - O7-1 (SGD1)	Always	Below 1 Ω

NG**REPAIR OR REPLACE FRONT SEAT WIRE RH****OK**

5 CHECK FRONT SEAT WIRE RH (SHORT)



- Disconnect the service wire from connector "C".
- Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
O7-7 (SIG1) - O7-1 (SGD1)	Always	1 MΩ or Higher
O7-11 (SVC1) - O7-1 (SGD1)	Always	1 MΩ or Higher
O7-7 (SIG1) - O7-11 (SVC1)	Always	1 MΩ or Higher

NG

REPAIR OR REPLACE FRONT SEAT WIRE RH

OK

6 CHECK FRONT SEAT WIRE RH (TO GROUND)



- Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
O7-1 (SGD1) - Body ground	Always	1 MΩ or Higher
O7-7 (SIG1) - Body ground	Always	1 MΩ or Higher
O7-11 (SVC1) - Body ground	Always	1 MΩ or Higher

NG

REPAIR OR REPLACE FRONT SEAT WIRE RH

OK

7 RECHECK DTC

- (a) Connect the connectors to the occupant classification ECU and the occupant classification sensor front LH.
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to the ON position.
- (d) Clear the DTCs stored in memory (see page [05-1215](#)).

HINT:

- First clear DTCs stored in the occupant classification ECU memory and then in the airbag sensor assy center memory.
 - Use the hand-held tester to clear the DTC of the occupant classification ECU, otherwise the DTC cannot be cleared.
- (e) Turn the ignition switch to the LOCK position.
 - (f) Turn the ignition switch to the ON position.
 - (g) Using the hand-held tester, check the DTCs (see page [05-1215](#)).

OK:

DTC B1780 is not output.

HINT:

Codes other than code B1780 may be output at this time, but they are not related to this check.

NG

Go to step 8

OK

USE SIMULATION METHOD TO CHECK (SEE PAGE [05-1207](#))

8 REPLACE OCCUPANT CLASSIFICATION ECU

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Replace the occupant classification ECU (see page [60-64](#)).

HINT:

Perform the inspection using parts from a normal vehicle when possible.

9 PERFORM ZERO POINT CALIBRATION

- (a) Using the hand-held tester, perform "Zero point calibration" (see page [05-1203](#)).

OK:

The "COMPLETED" is displayed.

NG

Go to step 12

OK

10 PERFORM SENSITIVITY CHECK

- (a) Using the hand-held tester, perform "Sensitivity check" (see page [05-1203](#)).

Standard value: 27 to 33 kg (59.52 to 72.75 lb)

NG

Go to step 12

OK

11 RECHECK DTC

- (a) Connect the negative (-) terminal cable to the battery.
(b) Turn the ignition switch to the ON position.
(c) Clear the DTCs stored in memory (see page [05-1215](#)).

HINT:

- First clear DTCs stored in the occupant classification ECU memory and then in the airbag sensor assy center memory.
 - Use the hand-held tester to clear the DTC of the occupant classification ECU, otherwise the DTC cannot be cleared.
- (d) Turn the ignition switch to the LOCK position.
(e) Turn the ignition switch to the ON position.
(f) Using the hand-held tester, check the DTCs (see page [05-1215](#)).

OK:

DTC B1780 is not output.

HINT:

Codes other than code B1780 may be output at this time, but they are not related to this check.

NG

Go to step 12

OK

END

12 REPLACE SEAT ADJUSTER FRAME ASSY

- (a) Turn the ignition switch to the LOCK position.
(b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
(c) Replace the seat adjuster frame assy (see page [72-11](#), [72-19](#)).

13 PERFORM ZERO POINT CALIBRATION

- (a) Using the hand-held tester, perform "Zero point calibration" (see page [05-1203](#)).

OK:

The "COMPLETED" is displayed.

14	PERFORM SENSITIVITY CHECK
-----------	----------------------------------

- (a) Using the hand-held tester, perform "Sensitivity check" (see page [05-1203](#)).
Standard value: 27 to 33 kg (59.52 to 72.75 lb)



END
