



TERMINALS OF ECU

1. **CHECK SLIDING ROOF DRIVE GEAR SUB- ASSY (SLIDING ROOF ECU)**
 - (a) Disconnect the sliding roof ECU connector, and check the voltage or continuity of each terminal of the wire harness side connector.

Symbols (terminal No.)	Wire color	Condition	Specified condition
ECUB (S20 - 5) - Body ground	B ↔ -	Constant	10 to 14 V
B (S20 - 7) - Body ground	L ↔ -	Constant	10 to 14 V
E (S20 - 7) - Body ground	W - B ↔ -	Constant	Continuity

If the result is not as specified, there may be a malfunction on the wire harness.