

## HOW TO PROCEED WITH TROUBLESHOOTING

**NOTICE:**

When DTCs other than U0073/94, U0123/62, U0124/95, U0126/63 are output, inspect and repair the trouble areas indicated by the DTCs.

1	CHECK CAN BUS LINE (SEE PAGE <a href="#">05-2102</a> )
---	--




2	CHECK AND CLEAR DTCs
---	----------------------

**HINT:**


When checking the DTCs for the skid control ECU, proceed to page [05-765](#)



3	CHECK DTC COMBINATION TABLE (SEE PAGE <a href="#">05-2101</a> )
---	---



4	CIRCUIT INSPECTION
---	--------------------



5	IDENTIFICATION OF PROBLEM
---	---------------------------



6	REPAIR OR REPLACE
---	-------------------



7	CONFIRMATION TEST
---	-------------------



END
-----