

REAR AXLE HUB & BEARING ASSY LH (4WD)


REPLACEMENT

3000N-02

HINT:

COMPONENTS: SEE PAGE 30-4

1. REMOVE REAR WHEEL
2. SEPARATE SPEED SENSOR REAR LH



3. REMOVE REAR AXLE SHAFT LH NUT


- (a) Using SST and a hammer, unstake the staked part of the axle hub LH nut.

SST 09930-00010

NOTICE:

Loosen the staked part of the nut completely, otherwise the screw of the drive shaft may be damaged.

- (b) While applying the brakes, remove the lock axle hub LH nut.




4. SEPARATE REAR DISC BRAKE CALIPER ASSY LH

- (a) Remove the bolt, and separate the flexible hose from the shock absorber.
- (b) Remove the 2 bolts and separate rear disc brake caliper assy.

NOTICE:


Use a string or other device to keep the brake caliper from hanging down.

5. REMOVE REAR DISC (SEE PAGE 32-29)




6. REMOVE REAR AXLE HUB & BEARING ASSY LH

- (a) Remove the 4 bolts and the rear axle hub & bearing assy LH.

**7. INSTALL REAR AXLE HUB & BEARING ASSY LH**


- (a) Install the rear axle hub & bearing assy LH with the 4 bolts.
Torque: 75 N·m (765 kgf·cm, 55 ft·lbf)

8. INSTALL REAR DISC (SEE PAGE 32-29)**9. INSTALL REAR DISC BRAKE CALIPER ASSY LH**

- (a) Install the rear disc brake caliper assy LH with the 2 bolts.
Torque: 78 N·m (800 kgf·cm, 58 ft·lbf)
 (b) Install the flexible hose with the bolt to the shock absorber.
Torque: 19 N·m (192 kgf·cm, 14 ft·lbf)

10. INSTALL REAR AXLE SHAFT LH NUT

- (a) Install a new axle shaft LH nut.
Torque: 294 N·m, (3,000 kgf·cm, 217 ft·lbf)

11. REMOVE REAR DISC BRAKE CALIPER ASSY LH**12. REMOVE REAR DISC****13. INSPECT BEARING BACKLASH (SEE PAGE 30-3)****14. INSPECT AXLE HUB DEVIATION (SEE PAGE 30-3)****15. INSTALL REAR DISC (SEE PAGE 32-29)****16. INSTALL REAR DISC BRAKE CALIPER ASSY LH****17. INSTALL REAR AXLE SHAFT LH NUT**

- (a) Install a new axle shaft LH nut.
Torque: 294 N·m, (3,000 kgf·cm, 217 ft·lbf)
 (b) Using a chisel and a hammer, stake the axle shaft LH nut.

18. INSTALL SPEED SENSOR REAR LH**19. INSTALL REAR WHEEL****20. CHECK ABS SPEED SENSOR SIGNAL (SEE PAGE 05-765)**