


OVERHAUL

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03-2).

1. REMOVE DECK BOARD SUB-ASSY (See page 76-21)



2. REMOVE REAR SEAT TRACK BRACKET COVER OUTER

- (a) Using a screwdriver, disengage the 4 claws and remove the bracket cover.

HINT:

Tape the screwdriver tip before use.

3. REMOVE REAR SEAT TRACK BRACKET COVER INNER

HINT:

Use the same procedures described for the bracket cover outer.


4. REMOVE REAR NO.1 SEAT ASSY LH

- (a) Using a clip remover, remove the 3 clips.

HINT:


Tape the clip remover tip before use.

- (b) Remove the bolt holding the fold seat stopper band on the vehicle side.
 (c) Remove the headrest.
 (d) Remove the 5 bolts and seat.



5. REMOVE REAR SEAT CUSHION MOULDING LH

- (a) Remove the 2 screws.
 (b) Remove the moulding by pulling it out in the arrow mark direction shown in the illustration.



6. REMOVE REAR SEAT CUSHION MOULDING REAR LH

- (a) Remove the 3 screws.
 (b) Using a screwdriver, disengage the 3 claws and remove the moulding.

HINT:

Tape the screwdriver tip before use.

7. REMOVE REAR SEAT CUSHION ASSY LH


- (a) Using a torx® socket wrench (T45), remove the 2 torx® bolts.
- (b) Remove the 2 bolts and cushion.

8. REMOVE SEPARATE TYPE REAR SEAT CUSHION COVER

- (a) Disengage the hook and remove the cushion cover together with the pad from the cushion.
- (b) Remove the hog rings and seat cushion cover.

9. REMOVE TONNEAU COVER HOOK HOLDER


- (a) Remove the 2 screws and 2 holders.

**10. REMOVE REAR SEATBACK COVER LH**


- (a) Using a screwdriver, disengage the 4 claws and remove the seatback cover.

HINT:

Tape the screwdriver tip before use.

**11. REMOVE REAR SEATBACK BOARD CARPET ASSY LH**

- (a) Remove the 4 clips and seatback board carpet.


**12. REMOVE REAR SEAT LOCK CONTROL LEVER SUB-ASSY LH**

- (a) Using a screwdriver, disengage the 2 claws and remove the seat lock control lever cover.

HINT:

Tape the screwdriver tip before use.


- (b) Remove the 2 screws.
- (c) Disconnect the reclining remote control cable and remove the seat lock control lever.

**13. REMOVE SEPARATE TYPE REAR SEATBACK COVER**

- (a) Remove the 2 headrest supports.
- (b) Using a clip remover, remove the 2 clips.
- (c) Disengage the hook and remove the seatback cover together with the pad from the seatback frame.
- (d) Remove the hog rings and seatback cover.

14. REMOVE FOLD SEAT STOPPER BAND ASSY NO.2

- (a) Remove the bolt and stopper band on the seat side.

15. DISCONNECT REAR SEAT RECLINING CONTROL NO. 2 CABLE**16. REMOVE REAR SEAT BELT ASSY INNER (See page 61-15)****17. REMOVE REAR SEAT RECLINING COVER INNER LH**

- (a) Remove the screw and the reclining cover in the direction indicated by the arrow in the illustration.

18. REMOVE REAR SEATBACK FRAME ASSY LH

- (a) Using a torx® socket wrench (T40), remove the 4 torx® bolts and seatback frame.

19. REMOVE RECLINING CONTROL LINK SUB-ASSY LH

- (a) Remove the 4 nuts and control link.

20. REMOVE SEAT TRACK STOP PLATE LH

- (a) Remove the 2 nuts and stop plate.

21. REMOVE REAR SEATBACK FRAME SUB-ASSY LOWER LH

- (a) Outer side:

Using a torx® socket wrench (T40), remove the 3 torx® bolts.

- (b) Inner side:


Using a torx® socket wrench (T55), remove the 2 torx® bolts and seatback frame.

22. REMOVE FOLD SEAT CUSHION FRAME NO.1

- (a) Remove the 2 nuts and cushion frame.

23. REMOVE FOLD SEAT CUSHION FRAME NO.2

- (a) Remove the 2 nuts and cushion frame.

**24. REMOVE REAR SEAT TRACK ADJUSTING HANDLE**

- (a) Using a screwdriver, push down the handle stopper to disengage the claw with the slide rail in the frontmost position. Remove the adjusting handle.

25. INSTALL FOLD SEAT CUSHION FRAME NO.1

- (a) Install the cushion frame with the 2 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

26. INSTALL FOLD SEAT CUSHION FRAME NO.2

- (a) Install the cushion frame with the 2 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

27. INSTALL REAR SEATBACK FRAME SUB-ASSY LOWER LH

- (a) Outer side:

Using a torx® socket wrench (T40), install the 3 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

- (b) Inner side:

Using a torx® socket wrench (T55), install the seatback frame with the 2 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

28. INSTALL REAR SEATBACK FRAME ASSY LH

- (a) Using a torx® socket wrench (T40), install the seatback frame with the 4 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

29. INSTALL SEAT TRACK STOP PLATE LH

- (a) Install the stop plate with the 2 nuts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

30. INSTALL RECLINING CONTROL LINK SUB-ASSY LH


- (a) Install the control link with the 4 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

31. INSTALL REAR SEAT BELT ASSY INNER (See page 61-15)**32. INSTALL FOLD SEAT STOPPER BAND ASSY NO.2**

- (a) Install the fold seat stopper band with the bolt.

Torque: 9.0 N·m (92 kgf·cm, 80 in·lbf)

**33. INSTALL SEPARATE TYPE REAR SEATBACK COVER**

- (a) Using hog ring pliers, install the seatback cover to the seatback pad with new hog rings.

- (b) Install the seatback cover to the seatback frame.

NOTICE:

- **Be careful not to damage the cover.**
 - **When installing the hog rings, take care to prevent wrinkles as much as possible.**
- (c) Install the 2 headrest supports.

34. INSTALL SEPARATE TYPE REAR SEAT CUSHION COVER

- (a) Using hog ring pliers, install the cushion cover to the cushion pad with new hog rings.

- (b) Install the cushion cover to the cushion frame.

NOTICE:

- **Be careful not to damage the cover.**
- **When installing the hog rings, take care to prevent wrinkles as much as possible.**

35. INSTALL REAR SEAT CUSHION ASSY LH

- (a) Hinge side:

Using a torx® socket wrench (T45), install the seat cushion with the 2 torx® bolts.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf)

- (b) Cushion side:

Install the seat cushion with the 2 bolts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

36. INSTALL REAR NO.1 SEAT ASSY LH

- (a) Place the seat in the cabin.

- (b) Install the seat with the 5 bolts.

Torque: 36.7 N·m (375 kgf·cm, 27 ft·lbf)

- (c) Install the fold seat stopper band with the bolt on the vehicle side.

Torque: 9.0 N·m (92 kgf·cm, 80 in·lbf)

- (d) Install the headrest.

- (e) When sliding the seat, check that both sides of the adjuster lock simultaneously.

HINT:

Check that the seat adjuster locks.