


OVERHAUL

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03-2).



1. REMOVE REAR SEAT TRACK BRACKET COVER OUTER

- (a) Using a screwdriver, disengage the 4 claws and remove the 2 covers.

HINT:

Tape the screwdriver tip before use.

2. REMOVE REAR SEAT TRACK BRACKET COVER INNER

HINT:



Use the same procedures described for the bracket cover outer.

3. REMOVE REAR SEAT TRACK BRACKET COVER OUTER RH

- (a) Using a screwdriver, disengage the 4 clips and remove the cover.

HINT:

Tape the screwdriver tip before use.



4. REMOVE REAR SEAT TRACK BRACKET COVER INNER RH


- (a) Using a screwdriver, disengage the claw and 3 clips and remove the cover.

HINT:

Tape the screwdriver tip before use.

5. REMOVE REAR NO.1 SEAT ASSY RH

- (a) Remove the headrest.
(b) Remove the 5 bolts and seat.




6. REMOVE REAR SEAT CUSHION MOULDING REAR RH

- Remove the 2 screws.
- Using a screwdriver, disengage the 4 claws and remove the moulding by pulling it out in the arrow mark direction shown in the illustration.

HINT:

Tape the screwdriver tip before use.




7. REMOVE REAR SEAT CUSHION MOULDING RH

- Remove the 2 screws.
- Using a screwdriver, disengage the 5 claws and remove the moulding by pulling it out in the arrow mark direction shown in the illustration.


HINT:

Tape the screwdriver tip before use.



8. REMOVE VERTICAL ADJUSTER BRACKET COVER OUTER

- Remove the screw.
- Disengage the 2 claws and remove the bracket cover by pulling it out in the arrow mark direction shown in the illustration.



9. REMOVE RECLINING HINGE COVER RH

- Disengage the 2 clips and 2 claws and remove the hinge cover by pulling it out in the arrow mark direction shown in the illustration.

10. REMOVE REAR SEAT CUSHION ASSY RH

- Using a torx® socket wrench (T45), remove the 2 bolts.
- Remove the 2 bolts and cushion.

11. REMOVE SEPARATE TYPE REAR SEAT CUSHION COVER

- (a) Disengage the hook and remove the cushion cover together with the pad from the cushion frame.
- (b) Remove the hog rings and seat cushion cover.

12. REMOVE SEAT TRACK UPPER RAIL COVER RH

- (a) Remove the 2 screws and rail cover.

13. REMOVE REMOTE CONTROL LEVER KNOB RH

- (a) Remove the screw and control lever knob.

14. REMOVE REAR SEAT COVER BEZEL NO.1

- (a) Using a screwdriver, disengage the 4 claws and remove the 2 covers.


HINT:

Tape the screwdriver tip before use.

- (b) Remove the 3 screws and seat cover bezel.

15. REMOVE TONNEAU COVER HOOK HOLDER


- (a) Remove the 2 screws and 2 holders.

**16. REMOVE REAR SEATBACK COVER RH**


- (a) Using a screwdriver, disengage the 4 claws and remove the seatback cover.

HINT:

Tape the screwdriver tip before use.

**17. REMOVE REAR SEATBACK BOARD CARPET ASSY RH**

- (a) Using a clip remover, disengage the 7 clips and remove seatback board carpet.


**18. REMOVE REAR SEAT LOCK CONTROL LEVER SUB-ASSY RH**

- (a) Using a screwdriver, disengage the 2 claws and remove the seat lock control lever cover.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 2 screws.
- (c) Disconnect the reclining remote control cable and remove the seat lock control lever.




19. REMOVE SEPARATE TYPE REAR SEATBACK COVER

- (a) Remove the 2 headrest supports.
- (b) Using a clip remover, remove the 2 clips.
- (c) Disengage the hook and remove the seatback cover together with the pad from the seatback frame.
- (d) Remove the hog rings and seatback cover.

20. DISCONNECT REAR SEAT RECLINING CONTROL NO. 2 CABLE

21. REMOVE REAR SEAT BELT ASSY INNER (See page 61-15)



22. REMOVE REAR SEAT RECLINING COVER INNER RH

- (a) Remove the screw and reclining cover by pulling out the cover in the arrow mark direction shown in the illustration.

23. REMOVE RECLINING ADJUSTER INSIDE COVER RH

- (a) Remove the screw and inside cover.

24. REMOVE REAR SEATBACK FRAME ASSY RH

- (a) Using a torx® socket wrench (T40), remove the 4 torx® bolts and seatback frame.

25. REMOVE RECLINING CONTROL LINK SUB-ASSY RH

- (a) Remove the 4 nuts and control link.

26. REMOVE SEAT TRACK STOP PLATE RH

- (a) Remove the 2 nuts and stop plate.

27. REMOVE REAR BACK LOCK CONTROL LEVER SUB-ASSY RH

- (a) Remove the 3 nuts and control lever.

28. REMOVE REAR SEATBACK FRAME SUB-ASSY LOWER LH

- (a) Outer side:

Using a torx® socket wrench (T40), remove the 3 torx® bolts.

- (b) Inner side:


Using a torx® socket wrench (T55), remove the 2 torx® bolts and seatback frame.

29. REMOVE FOLD SEAT CUSHION FRAME NO.1

- (a) Remove the 2 nuts and cushion frame.

30. REMOVE FOLD SEAT CUSHION FRAME NO.2

- (a) Remove the 2 nuts and cushion frame.



- 31. REMOVE REAR SEAT TRACK ADJUSTING HANDLE**
- (a) Using a screwdriver, push down the handle stopper to disengage the claw with the slide rail in the frontmost position. Remove the track adjusting handle.

32. INSTALL FOLD SEAT CUSHION FRAME NO.1

- (a) Install the cushion frame with the 2 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

33. INSTALL FOLD SEAT CUSHION FRAME NO.2

- (a) Install the cushion frame with the 2 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

34. INSTALL REAR SEATBACK FRAME SUB-ASSY LOWER LH

- (a) Outer side:

Using a torx® socket wrench (T40), install the 3 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

- (b) Inner side:

Using a torx® socket wrench (T55), install the seatback frame with the 2 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

35. INSTALL REAR SEATBACK FRAME ASSY RH

- (a) Using a torx® socket wrench (T40), install the seatback frame with the 4 torx® bolts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

36. INSTALL REAR BACK LOCK CONTROL LEVER SUB-ASSY RH

- (a) Install the control lever with the 3 nuts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

37. INSTALL SEAT TRACK STOP PLATE RH

- (a) Install the stop plate with the 2 nuts.


Torque: 18 N·m (184 kgf·cm, 13 ft·lbf)

38. INSTALL RECLINING CONTROL LINK SUB-ASSY RH

- (a) Install the control link with the 4 nuts.

Torque: 42 N·m (428 kgf·cm, 31 ft·lbf)

39. INSTALL REAR SEAT BELT ASSY INNER (See page 61-15)

**40. INSTALL SEPARATE TYPE REAR SEATBACK COVER**

- (a) Using hog ring pliers, install the seatback cover to the seatback pad with new hog rings.
- (b) Install the seatback cover to the seatback frame.

NOTICE:

- **Be careful not to damage the cover.**
 - **When installing the hog rings, take care to prevent wrinkles as much as possible.**
- (c) Install the 2 headrest supports.

41. INSTALL SEPARATE TYPE REAR SEAT CUSHION COVER

- (a) Using hog ring pliers, install the cushion cover to the cushion pad with new hog rings.

NOTICE:

- **Be careful not to damage the cover.**
 - **When installing the hog rings, take care to prevent wrinkles as much as possible.**
- (b) Install the cushion cover to the cushion frame.

42. INSTALL REAR SEAT CUSHION ASSY RH

- (a) Using a torx® socket wrench (T45), install seat cushion with the 2 torx® bolts.

Torque: 21 N·m (214 kgf·cm, 15 ft·lbf) for hinge side

- (b) Install the seat cushion with the 2 bolts.

Torque: 18 N·m (184 kgf·cm, 13 ft·lbf) for cushion side

43. INSTALL REAR NO.1 SEAT ASSY RH

- (a) Place the seat in the cabin.
- (b) Install the seat with the 4 bolts.
Torque: 36.7 N·m (375 kgf·cm, 27 ft·lbf)
- (c) Install the fold seat stopper band with the bolt on the vehicle side.
Torque: 9.0 N·m (92 kgf·cm, 80 in·lbf)
- (d) Install the headrest.
- (e) When sliding the seat, check that both sides of the adjuster lock simultaneously.

HINT:

Check that the seat adjuster locks.