

| | | |
|------------|--------------|--|
| DTC | P2769 | TORQUE CONVERTER CLUTCH SOLENOID CIRCUIT LOW (SHIFT SOLENOID VALVE DSL) |
|------------|--------------|--|

| | | |
|------------|--------------|---|
| DTC | P2770 | TORQUE CONVERTER CLUTCH SOLENOID CIRCUIT HIGH (SHIFT SOLENOID VALVE DSL) |
|------------|--------------|---|

CIRCUIT DESCRIPTION

The shift solenoid valve DSL is turned "ON" and "OFF" by signals from the ECM in order to control the hydraulic pressure operation, the lock-up relay valve, which then the controls operation of the lock-up clutch.

| DTC No. | DTC Detection Condition | Trouble Area |
|---------|--|--|
| P2769 | ECM detects short in solenoid valve DSL circuit (0.1 sec.) when solenoid valve DSL is operated (2-trip detection logic) | <ul style="list-style-type: none"> • Short in shift solenoid valve DSL circuit • Shift solenoid valve DSL • ECM |
| P2770 | ECM detects open in solenoid valve DSL circuit (0.1 sec.) when solenoid valve DSL is not operated (2-trip detection logic) | <ul style="list-style-type: none"> • Open in shift solenoid valve DSL circuit • Shift solenoid valve DSL • ECM |

MONITOR DESCRIPTION

Torque converter lock-up is controlled by the ECM based on engine rpm, engine load, engine temperature, vehicle speed, transmission temperature, and shift range selection. The ECM determines the lock-up status of the torque converter by comparing the engine rpm (NE) to the input turbine rpm (NT). The ECM calculates the actual transmission gear by comparing input turbine rpm (NT) to counter gear rpm (NC). When conditions are appropriate, the ECM requests "lock-up" by applying control voltage to shift solenoid DSL. When the DSL is opened, solenoid DSL applies pressure to the lock-up relay valve and locks the torque converter clutch. If the ECM detects an open or short in the DSL solenoid circuit, the ECM interprets this as a fault in the DSL solenoid or circuit. The ECM will turn on the MIL and store the DTC.

MONITOR STRATEGY

| | |
|-----------------------------|---|
| Related DTCs | P2769: Shift solenoid valve DSL/Range check (Low resistance) P2770: Shift solenoid valve DSL/Range check (High resistance) |
| Required sensors/Components | Shift solenoid valve DSL |
| Frequency of operation | Continuous |
| Duration | 0.064 sec. |
| MIL operation | 2 driving cycles |
| Sequence of operation | None |

TYPICAL ENABLING CONDITIONS

P2769: Range check (Low resistance)

| | |
|--|----------------------------------|
| The monitor will run whenever this DTC is not present. | See page 05-1007 |
| Shift solenoid valve DSL | ON |
| Solenoid current cut status | Not cut |
| Battery voltage | 8 V or more |
| Ignition switch | ON |
| Starter | OFF |

P2770: Range check (High resistance)

| | |
|--|----------------------------------|
| The monitor will run whenever this DTC is not present. | See page 05-1007 |
| Shift solenoid valve DSL | ON |
| Battery voltage | 8 V or more |
| Ignition switch | ON |
| Starter | OFF |

TYPICAL MALFUNCTION THRESHOLDS

P2769: Range check (Low resistance)

| | |
|-------------------------------------|--------------------|
| Shift solenoid valve DSL resistance | 8 Ω or less |
|-------------------------------------|--------------------|


P2770: Range check (High resistance)

| | |
|-------------------------------------|------------------------|
| Shift solenoid valve DSL resistance | 100 k Ω or more |
|-------------------------------------|------------------------|

COMPONENT OPERATING RANGE


| | |
|--------------------------|--|
| Shift solenoid valve DSL | Resistance: 11 to 13 Ω at 20°C (68°F) |
|--------------------------|--|

WIRING DIAGRAM



INSPECTION PROCEDURE

| | |
|---|--------------------------------|
| 1 | INSPECT TRANSMISSION WIRE(DSL) |
|---|--------------------------------|



- Disconnect the transmission wire connector from the transaxle.
- Measure the resistance according to the value(s) in the table below.


Standard:

| Tester Connection | Specified Condition 20°C (68°F) |
|-------------------|------------------------------------|
| 10 - Body ground | 11 to 13 Ω |

NG

Go to step 3


OK

2 CHECK HARNESS AND CONNECTOR(TRANSMISSION WIRE - ECM)

- Connect the transmission wire connector.
- Disconnect the ECM connector.
- Measure the resistance according to the value(s) in the table below.

Standard:

| Tester Connection | Specified Condition 20°C (68°F) |
|-----------------------------|------------------------------------|
| E8 - 11 (DSL) - Body ground | 11 to 13 Ω |

NG**REPAIR OR REPLACE HARNESS OR
CONNECTOR (SEE PAGE 01-36)****OK****REPLACE ECM (SEE PAGE 10-24)****3 INSPECT SHIFT SOLENOID VALVE(DSL)**

- Remove the shift solenoid valve DSL.
- Measure the resistance according to the value(s) in the table below.

Standard:

| Tester Connection | Specified Condition 20°C (68°F) |
|---|------------------------------------|
| Solenoid Connector (DSL) - Solenoid Body (DSL) | 11 to 13 Ω |

- Connect positive (+) lead to the terminal of solenoid connector, negative (-) lead to the solenoid body.

OK:**The solenoid valve makes an operating noise.****NG****REPLACE SHIFT SOLENOID VALVE(DSL)****OK****REPAIR OR REPLACE TRANSMISSION WIRE (SEE PAGE 40-37)**