

PROBLEM SYMPTOMS TABLE

If a normal system code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

HINT:

Inspect the fuse and relay before confirming the suspected area as shown in the charts below.

Inspect each malfunction circuit in numerical order for the corresponding symptom.

If the malfunction still exists even after checking and confirming that all the circuits are normal, replace the ECU.

1. HEADLAMP AND TAIL LAMP SYSTEM

| Symptom | Suspected Area | See page |
|--|--|--|
| "Low beam" does not come on (One side). | 3. Bulb 4. Wire harness or connector | - - |
| "Low beam" does not come on (Both sides). | 1. Bulb 2. Light control switch circuit 3. Headlight relay circuit (w/o Daytime running light) 4. DRL relay circuit (w/ Daytime running light) 5. Multiplex network body ECU | - 05-1586 05-1556 05-1562 - |
| "High beam" does not come on (One side). | 1. Bulb 2. Wire harness or connector | - - |
| "High beam" does not come on (Both sides). (Low beam is normal) | 1. Bulb 1. Light control switch circuit 2. DRL relay circuit (w/ Daytime running light) 3. Multiplex network body ECU | - 05-1586 05-1562 - |
| "Flash" does not come on. (Low beam and High beam are normal) | 1. Light control switch circuit 2. Multiplex network body ECU | 05-1586 - |
| Headlamp is dark. | 1. Bulb 2. Wire harness or connector | - - |
| Tail lamp does not come on (All). | 1. Light control switch circuit 2. TAIL relay circuit 3. Ignition switch circuit 4. Door courtesy switch circuit 5. Multiplex network body ECU | 05-1586 05-1574 05-1594 05-1601 - |
| Only one tail lamp comes on. | 1. Bulb 2. Wire harness or connector | - - |
| Daytime running light system does not operate. | 1. Light control switch circuit 2. Generator signal circuit 3. Parking brake switch circuit 4. Ignition switch circuit 5. DRL relay circuit 6. Multiplex network body ECU | 05-1586 05-1596 05-1598 05-1594 05-1562 - |

2. AUTOMATIC LIGHT CONTROL SYSTEM

| Symptom | Suspected Area | See page |
|--|---|--|
| Automatic light control system does not operate. | 1. Light control switch circuit 2. Ignition switch circuit 3. Automatic light control sensor circuit 4. Multiplex network body ECU | 05-1586 05-1594 05-1589 - |

3. LIGHT AUTO TURN OFF SYSTEM

| Symptom | Suspected Area | See page |
|--|---|--|
| Light auto turn off system does not operate. | 1. Light control switch circuit 2. Ignition switch circuit 3. Door courtesy switch circuit 4. Multiplex network body ECU | 05-1586 05-1594 05-1601 - |

4. FOG LAMP SYSTEM

| Symptom | Suspected Area | See page |
|---|--|---|
| Front fog lamp does not come on with light control switch in the TAIL or HEAD position. | 1. Light control switch circuit 2. Front fog light circuit 3. Multiplex network body ECU | 05-1586 05-1582 - |
| Only one front fog lamp does not come on. | 1. Bulb 2. Wire harness or connector | - - |

5. TURN SIGNAL AND HAZARD WARNING SYSTEM

| Symptom | Suspected Area | See page |
|--|--|--------------------------------|
| "Hazard" and "Turn" do not come on. | 1. Ignition switch 2. Turn signal flasher relay 3. Wire harness or connector | - 65-2 - |
| Hazard warning light does not come on. (Turn is normal) | 1. Hazard warning switch 2. Wire harness or connector | 65-4 - |
| Turn signal does not come on. (Hazard is normal) | 1. Headlamp dimmer switch (turn signal switch) 2. Wire harness or connector | 65-4 - |
| Turn signal does not come on in one direction. | 1. Headlamp dimmer switch (turn signal switch) 2. Wire harness or connector | 65-4 - |
| Only one bulb does not come on. | 1. Bulb 2. Wire harness or connector | - - |

6. STOP LIGHT SYSTEM

| Symptom | Suspected Area | See page |
|---------------------------------------|--|---------------------------|
| Stop light does not operate (All). | 1. Stop light switch 2. Wire harness or connector | 65-4 - |
| Only one stop light does not operate. | 1. Bulb 2. Wire harness or connector | - - |

7. ILLUMINATED ENTRY SYSTEM

| Symptom | Suspected Area | See page |
|---|--|---|
| Illuminated entry of multiplex network body ECU control does not operate (All). | 1. Ignition switch circuit 2. Door lock position circuit 3. Door courtesy switch circuit 4. Illumination circuit 5. Multiplex network body ECU | 05-1594 05-1604 05-1601 05-1606 - |

8. OTHERS

| Symptom | Suspected Area | See page |
|---|--|---|
| Back up lamp does not come on (All). | 1. Park/neutral position switch 2. Wire harness or connector | 05-922 or 05-1036 - |
| Vanity light does not operate. | 1. Bulb 2. Wire harness or connector | - - |
| Door courtesy lamp does not come on. | 1. Bulb 2. Door courtesy switch circuit 3. Wire harness or connector 4. Multiplex network body ECU | - 05-1601 - - |
| Luggage compartment light does not come on. (When back door is opened) | 1. Rear interior light 2. Back door courtesy switch 3. Wire harness or connector | 65-4 65-4 - |
| Luggage compartment light does not come on. (When rear door is opened) | 1. Rear interior light 2. Door courtesy switch circuit 3. Wire harness or connector 4. Multiplex network body ECU | 65-4 05-1601 - - |