

LIST OF DISABLE A MONITOR

HINT:

This table indicates ECM monitoring status for the items in the upper columns if the DTCs in each line on the left are being set.

As for the "X" mark, when the DTC on the left is stored, detection of the DTC in the upper column is not performed.

Monitor detected malfunction	Fault code			Monitor disablement (× – disabled)																															
	Fault code	Component/ system		P0010, P0020	P0011	P0012	P0016, P0018	P0021	P0022	P0030, 50	P0135, P0155	P0036, 56	P0043, 44, 63, 64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120- P0223, P2135	P0125	P0128	P0130- P0153	P0134, P0154	P0136, P0156	P0142, P0162	P0171, P0172	P0300- P0308						
	Fault code	Component/ system		P0010, P0020	P0011	P0012	P0016, P0018	P0021	P0022	P0030, 50	P0135, P0155	P0036, 56	P0043, 44, 63, 64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120- P0223, P2135	P0125	P0128	P0130- P0153	P0134, P0154	P0136, P0156	P0142, P0162	P0171, P0172	P0300- P0308						
Monitor detected malfunction	P0010, P0020	VVT VSV 1, 2																					×												
	P0011	VVT System 1 – Advance		×			×	×															×					×							
	P0012	VVT System 1 – Retard			×				×														×												
	P0016, P0018	VVT System – Misalignment																					×												
	P0021	VVT System 2 – Advance				×	×																	×				×							
	P0022	VVT System 2 – Retard				×	×		×															×				×							
	P0030, 50	O2 Sensor Heater–Sensor1								×														×	×	×	×	×	×						
	P0135, P0155	A/F Sensor Heater–Sensor1									×													×		×	×	×	×						
	P0036, 56	O2 Sensor Heater–Sensor2										×														×	×								
	P0043, 44, 63, 64	O2 Sensor Heater–Sensor3											×														×								
	P0100, P0101	MAF sensor			×	×		×	×					×							×		×	×	×	×	×	×	×	×					
	P0105, P0106	MAP sensor			×	×		×	×												×		×	×	×	×	×	×	×	×					
	P0110	IAT sensor																					×	×	×	×	×	×	×	×					
	P0115, P0116	ECT sensor			×	×	×	×	×							×		×					×	×	×	×	×	×	×	×					
	P0120, P0121	TP sensor														×		×							×	×	×	×	×	×					
	P0125	Insufficient ECT for Closed Loop			×	×		×	×							×		×						×	×	×	×	×	×	×					
	P0128	Thermostat																							×	×	×	×	×	×					
	P0130- P0153	O2 Sensor–Sensor1																							×	×	×	×	×						
	P0134, P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1										×													×	×	×	×	×	×					
	P0136, P0156	O2 Sensor–Sensor2																									×	×	×	×					
	P0142, P0162	O2 Sensor–Sensor3																										×	×	×					
	P0171, P0172	Fuel system																							×	×	×	×	×	×					
	P0300- P0308	Misfire									×														×	×	×	×	×	×					
	P0325, P0330	Knock sensor																												×					
	P0335	CKP sensor			×	×		×	×							×		×							×	×	×	×	×	×					
	P0340, P0341	CMP sensor			×	×		×	×							×		×							×	×	×	×	×	×					
	P0340- P0346	VVT sensor 1, 2																							×										
	P0351- P0358	Ignitor			×	×		×	×																×				×						
	P0385	CKP sensor 2														×		×							×	×	×	×	×	×					
	P0401	EGR system (closed)																							×		×	×	×	×					
	P0402	EGR system (open)																							×	×	×	×	×	×					
	P0405, P0409	Lift sensor																									×	×	×						
	P0420, P0430	Catalyst																								×	×	×	×						
	P0442- P0456	EVAP system																								×	×	×	×						
	P0450, P0451	EVAP press sensor																																	

P

A92385

A9864

3

P A92385

A98648

Monitor detected malfunction	Fault code			Monitor disablement (X – disabled)																			
	Fault code			Monitor disablement (X – disabled)																			
	Fault code			Monitor disablement (X – disabled)																			
	Component/ system			P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0030,50	P0031,32,51,52	P0031,32,51,52	P0037,38,57,58	P0036,56	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121
	P0500	P0500	VSS	VVT VSV 1, 2																			
	P0511	P0511	IAC valve	VVT System 1 – Advance																			
	P0510	P0510	Idle switch	VVT System 1 – Retard																			
	P0560	P0560	System Voltage	VVT System – Misalignment																			
	P0617	P0617	Starter signal	VVT System 2 – Advance																			
	P0705	P0705	Shift lever position switch	VVT System 2 – Retard																			
	P0710	P0710-P0713	Trans fluid temp sensor	O2 Sensor Heater-Sensor1																			
	P0720-P0793	P0720-P0793	Output speed sensor	A/F Sensor Heater-Sensor1																			
	P0715-P0717	P0715-P0717	Input speed sensor	O2 Sensor Heater-Sensor2																			
	P0724	P0724	Stop lamp switch	O2 Sensor Heater-Sensor3																			
	P0741-P0796	P0741-P0796	Trans solenoid (function)	MAF sensor																			
	P0748-P0798	P0748-P0798	Trans solenoid (range)	MAF sensor																			
	P0850	P0850	PNP switch	MAP sensor																			
	P1010,P1020	P1010,P1020	VVTL	MAP sensor																			
	P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)	MAP sensor																			
	P1126	P1126	Electronic magnet clutch	IAT sensor																			
	P1129	P1129	Electronic throttle system	ECT sensor																			
	P1430	P1430	HC adsorber ACT press sensor	TP sensor																			
	P2004,6	P2004,6	Intake Manifold Runner Control	Insufficient ECT for Closed Loop																			
	P2009,10	P2009,10	Intake Manifold Runner Control Circuit	Thermostat																			
	P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor	O2 Sensor-Sensor1																			
	P2102,P2103	P2102,P2103	Throttle motor	O2 Sensor A/F sensor (No Activity)-Sensor1																			
	P2120-P2138	P2120-P2138	Accel position sensor	O2 Sensor-Sensor2																			
	P2196,P2198	P2196,P2198	A/F sensor (rationality)	O2 Sensor-Sensor3																			
	P2226	P2226	BARO sensor	Fuel system																			
	P2237,2240	P2237,2240	A/F sensor (open)	Misfire																			
	P2423,24	P2423,24	HC Absorption Catalyst																				
	P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)																				
	P2431	P2431	A/R Pressure Sensor (Rationality)																				
	P2440	P2440	A/R control valve stuck open																				
	P2441	P2441	A/R control valve stuck close																				
	P2444	P2444	AIP stuck On																				
	P2445	P2445	AIP stuck Off																				
	P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)																				
	P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)																				

P

A92386

2005 HIGHLANDER REPAIR MANUAL (RM1144U)

Monitor detected malfunction	Fault code			Monitor disablement (X – disabled)																		
	Fault code			Monitor disablement (X – disabled)																		
	Fault code			Monitor disablement (X – disabled)																		
	Component/ system			Monitor disablement (X – disabled)																		
Monitor detected malfunction	P0500	P0500	VSS																			
	P0511	P0511	IAC valve																			
	P0510	P0510	Idle switch																			
	P0560	P0560	System Voltage																			
	P0617	P0617	Starter signal																			
	P0705	P0705	Shift lever position switch																			
	P0710	P0710-P0713	Trans fluid temp sensor																			
	P0720-P0793	P0720-P0793	Output speed sensor																			
	P0715-P0717	P0715-P0717	Input speed sensor																			
	P0724	P0724	Stop lamp switch																			
	P0741-P0796	P0741-P0796	Trans solenoid (function)																			
	P0748-P0798	P0748-P0798	Trans solenoid (range)																			
	P0850	P0850	PNP switch																			
	P1010,P1020	P1010,P1020	VVTL																			
	P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)																			
	P1126	P1126	Electronic magnet clutch																			
	P1129	P1129	Electronic throttle system																			
	P1430	P1430	HC adsorber ACT press sensor																			
	P2004,6	P2004,6	Intake Manifold Runner Control																			
	P2009,10	P2009,10	Intake Manifold Runner Control Circuit																			
	P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor																			
	P2102,P2103	P2102,P2103	Throttle motor																			
	P2120-P2138	P2120-P2138	Accel position sensor																			
	P2196,P2198	P2196,P2198	A/F sensor (rationality)																			
	P2226	P2226	BARO sensor																			
	P2237,2240	P2237,2240	A/F sensor (open)																			
	P2423,24	P2423,24	HC Absorption Catalyst																			
	P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)																			
	P2431	P2431	A/R Pressure Sensor (Rationality)																			
	P2440	P2440	A/R control valve stuck open																			
	P2441	P2441	A/R control valve stuck close																			
	P2444	P2444	AIP stuck On																			
	P2445	P2445	AIP stuck Off																			
	P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)																			
	P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)																			

P

A92388

Monitor detected malfunction				Monitor disablement (× – disabled)																									
	Fault code																												
	Fault code																												
	Component/ system																												
P0010,P0020	P0010,P0020	VVT VSV 1, 2																											
P0011	P0011	VVT System 1 – Advance																											
P0012	P0012	VVT System 1 – Retard																											
P0016,P0018	P0016,P0018	VVT System – Misalignment																											
P0021	P0021	VVT System 2 – Advance																											
P0022	P0022	VVT System 2 – Retard																											
P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1																											
P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1																											
P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2																											
P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3																											
P0100,P0101	P0100-P0103	MAF sensor																											
P0105,P0106	P0105-P0108	MAP sensor																											
P0110	P0110-P0113	IAT sensor																											
P0115,P0116	P0115-P0118	ECT sensor	×																										
P0120,P0121	P0120-P0223,P2135	TP sensor																											
P0125	P0125	Insufficient ECT for Closed Loop	×																										
P0128	P0128	Thermostat																											
P0130-P0153	P0130-P0153	O2 Sensor–Sensor1																											
P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1																											
P0136,P0156	P0136,P0156	O2 Sensor–Sensor2																											
P0142,P0162	P0142,P0162	O2 Sensor–Sensor3																											
P0171,P0172	P0171,P0172	Fuel system																											
P0300-P0308	P0300-P0308	Misfire																											
P0325,P0330	P0325-P0333	Knock sensor																											
P0335	P0335	CKP sensor																											
P0340,P0341	P0340,P0341	CMP sensor																											
P0340-P0346	P0340-P0346	VVT sensor 1, 2																											
P0351-P0358	P0351-P0358	Ignitor																											
P0385	P0385	CKP sensor 2																											
P0401	P0401	EGR system (closed)																											
P0402	P0402	EGR system (open)																											
P0405,P0409	P0405-P0409	Lift sensor																											
P0420,P0430	P0420,P0430	Catalyst																											
P0442-P0456	P0442-P0456	EVAP system																											
P0450,P0451	P0450-P0453	EVAP press sensor																											

P

A92389

Monitor detected malfunction	Fault code			Monitor disablement (X – disabled)																											
	Fault code	Fault code	Component/ system	P0741-P0796	P0748-P0798	P0850	P1010,P1020	P1011,12(,21,22)	P1126	P1129	P1430	P2004,6	P2009,P2010	P2014,16,17	P2102,P2103	P2120-P2138	P2196,P2198	P2226	P2237,P2240	P2423,24	P2430,2,3	P2431	P2440	P2441	P2444	P2445	P2714-P2759	P2A00,P2A03			
				P0741-P0796	P0748-P0798	P0850	P1010,P1020	P1011,12(,21,22)	P1126	P1129	P1430	P2004,6	P2009,10	P2014,16,17	P2102,P2103	P2120-P2138	P2196,P2198	P2226	P2237,P2240	P2423,24	P2430,2,3	P2431	P2440	P2441	P2444	P2445	P2714-P2759	P2A00,P2A03			
				P0741-P0796	P0748-P0798	P0850	P1010,P1020	P1011,12(,21,22)	P1126	P1129	P1430	P2004,6	P2009,10	P2014,16,17	P2102,P2103	P2120-P2138	P2196,P2198	P2226	P2237,P2240	P2423,24	P2430,2,3	P2431	P2440	P2441	P2444	P2445	P2714-P2759	P2A00,P2A03			
P0500	P0500	VSS	X																												
P0511	P0511	IAC valve																													
P0510	P0510	Idle switch																													
P0560	P0560	System Voltage																													
P0617	P0617	Starter signal																													
P0705	P0705	Shift lever position switch																													
P0710	P0710-P0713	Trans fluid temp sensor																													
P0720-P0793	P0720-P0793	Output speed sensor																													
P0715-P0717	P0715-P0717	Input speed sensor																													
P0724	P0724	Stop lamp switch																													
P0741-P0796	P0741-P0796	Trans solenoid (function)																													
P0748-P0798	P0748-P0798	Trans solenoid (range)	X																												
P0850	P0850	PNP switch																													
P1010,P1020	P1010,P1020	VVTL																													
P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)																													
P1126	P1126	Electronic magnet clutch																													
P1129	P1129	Electronic throttle system																													
P1430	P1430	HC adsorber ACT press sensor																													
P2004,6	P2004,6	Intake Manifold Runner Control																													
P2009,10	P2009,10	Intake Manifold Runner Control Circuit																													
P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor																													
P2102,P2103	P2102,P2103	Throttle motor																													
P2120-P2138	P2120-P2138	Accel position sensor																													
P2196,P2198	P2196,P2198	A/F sensor (rationality)																													
P2226	P2226	BARO sensor																													
P2237,2240	P2237,2240	A/F sensor (open)																													
P2423,24	P2423,24	HC Absorption Catalyst																													
P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)																													
P2431	P2431	A/R Pressure Sensor (Rationality)																													
P2440	P2440	A/R control valve stuck open																													
P2441	P2441	A/R control valve stuck close																													
P2444	P2444	AIP stuck On																													
P2445	P2445	AIP stuck Off																													
P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)																													
P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)																													

A923

P

A92390