


ACCELERATOR PEDAL ROD ASSY (2AZ-FE) REPLACEMENT

100MI-01



1. REMOVE ACCELERATOR PEDAL ROD ASSY

- (a) Disconnect the accelerator pedal position sensor connector.
- (b) Remove the 2 bolts and pedal rod.

2. INSTALL ACCELERATOR PEDAL ROD ASSY

- (a) Install the pedal rod with the 2 bolts.
Torque: 4.9 N·m (50 kgf·cm, 43 in.·lbf)
- (b) Connect the accelerator pedal position sensor connector.