



Service Hints

T9 Towing Converter

- 3-Ground : Approx. 12 volts with the light control SW at TAIL or HEAD position
- 8-Ground : Always approx. 12 volts
- 5-Ground : Always continuity
- 9-Ground : Approx. 12 volts with the stop light SW on

S15 Stop Light SW

- 1-2 : Closed with the brake pedal depressed

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A10	42	J12	44	S15	43
B9	42	J13	44	T8	43
C13	42	J20	43	T9	45
J10	44	M3	43	T10	45

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	29	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1E		
1H		
2B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2F		
3B	30	Instrument Panel Wire and Center J/B (Behind the Instrument Panel Center)
3E		
4C	33	Cowl Wire and Passenger Side J/B (Right Side of Grove Box)
4E		
4G		
4L	32	
4M		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	52	Cowl Wire and Floor No.2 Wire (Left Kick Panel)
IA2		
IC2	52	Engine Room Main Wire and Cowl Wire (Left Cowl Side Panel)
IC3		
IL2	54	Instrument Panel Wire and Cowl Wire (Upper Side of Passenger Side J/B)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IA	52	Left Cowl Side Panel
BC	56	Left Side of Rear Cross Member

⬡ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B9	56	Floor No.2 Wire			

