



## Service Hints

### R24 Rear Heater Main SW

6-Ground : Approx. 12 volts with the ignition SW at ON position

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J5	<a href="#">43</a>	R24	<a href="#">43</a>	R26	<a href="#">45</a>
J19	<a href="#">44</a>	R25	<a href="#">45</a>	R27	<a href="#">45</a>

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	<a href="#">22</a>	Engine Room R/B (Engine Compartment Left)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1G	<a href="#">29</a>	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1K	<a href="#">28</a>	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	<a href="#">52</a>	Cowl Wire and Floor No.2 Wire (Left Kick Panel)
IK2	<a href="#">54</a>	Engine Room Main Wire and Cowl Wire (Right Cowl Side Panel)
IO1	<a href="#">54</a>	Cowl Wire and Floor Wire (Right Kick Panel)
IR1	<a href="#">54</a>	Instrument Panel Wire and Floor Wire (Under the Shift Lever)
BH1	<a href="#">56</a>	Floor No.2 Wire and Floor Wire (Near the Rear Side Marker Light RH)

## : GROUND POINTS

Code	See Page	Ground Points Location
BB	<a href="#">56</a>	Right Center Pillar
BF	<a href="#">56</a>	Near the Rear Side Marker Light RH