

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All doors are not operated by driver's door key cylinder for interlocked with key	<ol style="list-style-type: none"> 1. Body ECU monitor code 2. Front door lock assy RH (driver side) 3. Wire harness 4. Power window regulator master switch assy (Door ECU) 	05-1954
Key confinement prevention function does not work properly (Manual operation and operation interlocked with key are active)	<ol style="list-style-type: none"> 1. Un-lock warning switch assy 2. Wire harness 3. Door open warning Light (built in combination meter) 4. Front door courtesy lamp switch assy (driver side) 	05-1957
Door lock system does not operate at all	<ol style="list-style-type: none"> 1. Door 20 A fuse 2. Multiplex Network Body ECU 3. Wire harness 	05-2046
Door lock system does not operate by manual switch	<ol style="list-style-type: none"> 1. Power window regulator master switch assy (door ECU) (Door control switch for manual operation) 2. Multiplex Network Body ECU 3. Wire harness 	05-2046
Fault in key confinement prevention operate	<ol style="list-style-type: none"> 1. Multiplex Network Body ECU 2. Un-lock warning switch assy 3. Front door courtesy lamp switch assy (driver side) 4. Wire harness 	05-1957
Only one door lock does not operate	<ol style="list-style-type: none"> 1. Door lock assy 2. Wire harness 	73-3
Fault in 2-operation unlock function of driver side door key lock and unlock switch	<ol style="list-style-type: none"> 1. Door key lock and unlock switch circuit 2. Power window regulator master switch assy (Door ECU) 3. Multiplex Network Body ECU 4. Wire harness 	73-3