


FRONT NO.1 SPEAKER ASSY REPLACEMENT


6715U-01

HINT:

- COMPONENTS: See page 67-2
 - Installation is in the reverse order of removal.
1. REMOVE MULTIPLEX NETWORK MASTER SWITCH ASSY (SEE PAGE 75-6)
 2. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH (SEE PAGE 75-6)
 3. REMOVE DOOR PULL HANDLE (SEE PAGE 75-6)
 4. REMOVE FRONT DOOR TRIM BOARD SUB-ASSY LH (SEE PAGE 75-6)
 5. REMOVE FRONT DOOR INSIDE HANDLE SUB-ASSY LH (SEE PAGE 75-6)

**6. REMOVE FRONT NO.1 SPEAKER ASSY**

- (a) Disconnect the connector.
- (b) Remove the 3 screws and front No. 1 speaker assy.

**7. INSTALL FRONT NO.1 SPEAKER ASSY**

- (a) Install the front No.1 speaker assy with the 3 screws.
- (b) Connect the connector.