

COMBINATION METER

PROBLEM SYMPTOMS TABLE

7101E-06

Warning Lights:

Symptom	Suspect Area	See page
Check Engine warning light does not come on.	7. ECM 8. Wire Harness or Connector 9. Combination Meter Assy	05-5 05-366 - 71-18
Discharge warning light does not come on.	1. ECM 2. Wire Harness or Connector 3. Combination Meter Assy	05-5 05-366 - 71-18
Brake warning light does not come on.	1. Skid control ECU 2. Wire Harness or Connector 3. Combination Meter Assy	05-761 - 71-18
ABS warning light does not come on.	1. ABS ECU 2. Wire Harness or Connector 3. Combination Meter Assy	05-761 - 71-18
SRS warning light does not come on.	1. Airbag Sensor Assy Center 2. Wire Harness or Connector 3. Combination Meter Assy	05-1200 - 71-18
Open Door warning light does not come on.	1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy	05-1601 - 71-18
Fuel Level warning light does not come on.	1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy	05-1893 - 71-18
Low Oil Pressure warning light does not come on.	1. Low Oil Pressure Warning Switch 2. Wire Harness or Connector 3. Combination Meter Assy	71-3 - 71-18
Driver's seat belt warning light does not come on.	1. Refer to troubleshooting 2. Wire Harness or Connector 3. Combination Meter Assy	05-1898 - 71-18
"OIL LEVEL" warning light does not come on.	1. Low Oil Level Sensor 2. Wire Harness or Connector 3. ECM 4. Combination Meter Assy	05-5 05-366 - 05-5 05-366 71-18
"TIRE AIR PRESS" warning light does not come on.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-761 71-18

Indicator Lights:

Symptom	Suspect Area	See page
Turn indicator light does not come on.	1. Turn Signal and Hazard Warning System 2. Wire Harness or Connector 3. Combination Meter Assy	05-1533 - 71-18
High Beam indicator light does not come on.	1. Headlight Dimmer Switch 2. Wire Harness or Connector 3. Combination Meter Assy	05-1533 - 71-18
Washer level indicator light does not come on.	1. Washer Level Warning Switch 2. Wire Harness or Connector 3. Combination Meter Assy	- - 71-18

MAINT REQD indicator is blinking or continuously illuminated.	1. Resetting procedure 2. Combination Meter Assy	71-3 71-18
All buzzer (key reminder, tail cancel, Seat belt) does not operate.	1. Refer to troubleshooting 2. Combination Meter Assy	05-1879 71-18
O/D OFF indicator light does not come on.	1. O/D off Select Switch 2. Wire Harness or Connector 3. Combination Meter Assy	- - 71-18
SLIP indicator light does not come on.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-761 71-18
VSC indicator light does not come on.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-761 71-18
TRC/TRAC OFF indicator light does not come on.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-761 71-18
A/T OIL TEMP indicator light does not come on.	1. Wire Harness or Connector 2. Automatic transmission 3. Combination Meter Assy	- 05-883 05-993 71-18
ECT SNOW indicator light does not come on.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	- 05-5 05-366 71-18
A/T shift indicator light does not come on.	1. Park Neutral Position Switch 2. Wire Harness or Connector 3. ECM 4. Combination Meter Assy	05-883 05-993 - 05-5 05-366 71-18
"CRUISE" indicator light does not come on.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	- 05-5 05-366 71-18

Meter Gauges:

Symptom	Suspect Area	See page
Speedometer does not operate.	1. Refer to troubleshooting	05-1885
Tachometer does not operate.	1. Refer to troubleshooting	05-1889
Fuel Gauge does not operate or operates abnormally.	1. Refer to troubleshooting	05-1893
Water temperature does not operate.	1. Refer to troubleshooting	05-1896

Clock:

Symptom	Suspect Area	See page
Clock will not operate Clock loses or gains time	1. Power source or ground 2. Integration control & panel assy	05-1170 05-1173 05-1175 71-6