


Garage Door Opener

From Power Source System (See Page 62)



Service Hints

V9 Garage Door Opener

- 1-Ground : Always approx. 12 volts
- 2-Ground : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
V9	45				

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	29	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1E		
2A	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
4D	33	Cowl Wire and Passenger Side J/B (Right Side of Grove Box)
4H		
4L	32	
4M		
4N		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IE1	52	Roof Wire and Cowl Wire (Near the Bottom of Left Front Pillar)
IK3	54	Engine Room Main Wire and Cowl Wire (Right Cowl Side Panel)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IA	52	Left Cowl Side Panel
IC	52	Right Cowl Side Panel