

COMPRESSOR CIRCUIT


CIRCUIT DESCRIPTION

The ECM and A/C amplifier communicate via BEAN.

The A/C amplifier assy outputs the magnetic clutch ON signal to the ECM.

Receiving this signal, the ECM sends a signal through terminal ACMG and switches the magnetic clutch relay ON, thus turning on the magnetic clutch.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the items below in the DATA LIST, and read the displays on the hand-held tester.

ENGINE AND ECT / ALL:

Item	Measurement Item/Display (Range)	Normal Condition	Diagnostic Note
A/C SIG	A/C signal/ ON or OFF	A/C ON: ON	-
A/C MAG CLUTCH	A/C magnet clutch/ ON or OFF	A/C magnet clutch ON: ON	-

NG

INSPECT MULTIPLEX COMMUNICATION CIRCUIT

OK

2 PERFORM ACTIVE TEST USING HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the item below in the ACTIVE TEST, and then check that the relay operates.

ENGINE AND ECT / ALL:

Item	Test Details/Display (Range)	Diagnostic Note
A/C MAG CLUTCH	Magnetic clutch relay / OFF, ON	Operating sound can be heard

NG


Go to step 3

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1 129)

3

INSPECT MAGNET-CLUTCH RELAY



- (a) Remove the relay (magnet clutch relay) from the engine room R/B.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
3 - 5	Always	10 kΩ or higher
3 - 5	When battery voltage applied to terminals 1 and 2	Below 1 Ω


NG

REPLACE MAGNET-CLUTCH RELAY

OK

4

INSPECT MAGNET CLUTCH ASSY



- (a) Disconnect the connector from the magnet clutch assy.
- (b) Connect the positive (+) lead from the battery to terminal 3 and negative (-) lead to body ground, then check that the magnet clutch assy is engaged.


NG

REPLACE MAGNET CLUTCH ASSY

OK

5

INSPECT ECM



- (a) Remove the ECM and disconnect the connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
E6-2 (ACMG) - Body ground	Ignition switch ON	10 to 14 V

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR


OK

6

CHECK HARNESS AND CONNECTOR

ECM Connector


Wire Harness View:



ACMG

Magnet Clutch Assy Connector

Wire Harness View:



I36159
E51630

I38853

- (a) Disconnect the connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A2-3 - Body ground	Ignition switch ON When using service wire, terminal E6-2 (ACMG) and Body ground are not connect	Below 1 V
A2-3 - Body ground	Ignition switch ON When using service wire, terminal E6-2 (ACMG) and Body ground are connect	10 to 14 V

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE ECM