

## DIAGNOSTIC TROUBLE CODE CHART

### 1. DIAGNOSTIC TROUBLE CODE

#### Door ECU (driver side)

DTC Code	Item	Diagnosis
B1231/31	Driver side jam protection limit switch malfunctions	Power window regulator motor assy RH open in limit switch system
B1232/32	Driver side jam protection sensor malfunctions	Power window regulator motor assy RH open or short in pulse sensor system

### 2. MONITOR CODE

#### HINT:

- The monitor code shows the switch condition when a DTC is output.
- When a monitor code is indicated while the switch is not operated, the switch is detected in being stuck. When a monitor code is not indicated while the switch is operated, it is detected that the switch contact condition is bad.

DTC Code	Item	Monitor Item
B1221/21	Driver side switch 1 (operating)	Any switch of the power window regulator master switch is ON