

CHECK FOR INTERMITTENT PROBLEMS

Hand-held tester only:

Inspect the vehicle's ECM using check mode. Intermittent problems are easier to detect when the ECM is in check mode with the hand-held tester. In check mode, the ECM uses 1 trip detection logic, which has a higher sensitivity to malfunctions than normal mode (default), which uses 2 trip detection logic.

- (a) Clear the DTCs (see page [05-38](#)).
- (b) Set the check mode (see page [05-40](#)).
- (c) Perform a simulation test (see page [01-26](#)).
- (d) Check the connector and terminal (see page [01-36](#)).
- (e) Wiggle the harness and the connector (see page [01-36](#)).