


VENTILATION VALVE SUB-ASSY (3MZ-FE)

120BR-04

REPLACEMENT

1. REMOVE VENTILATION VALVE SUB-ASSY

- (a) Disconnect the ventilation hose from the ventilation valve.
- (b) Remove the ventilation valve.



2. INSTALL VENTILATION VALVE SUB-ASSY

- (a) Install the ventilation valve.
 - (1) Apply adhesive to 2 or 3 threads.
Adhesive:
Part No. 08833-00070, THREE BOND 1324 or equivalent
 - (2) Install the ventilation valve.
Torque: 19 N·m (193 kgf·cm, 14 ft·lbf)
- (b) Connect the ventilation hose to the ventilation valve.