

|            |                 |                                       |
|------------|-----------------|---------------------------------------|
| <b>DTC</b> | <b>C1223/43</b> | <b>ABS CONTROL SYSTEM MALFUNCTION</b> |
|------------|-----------------|---------------------------------------|

## CIRCUIT DESCRIPTION

### HINT:

- This DTC is output when the VSC system detects a malfunction in the ABS system.
- When DTC C1223/43 is memorized, there is no malfunction in the skid control ECU.

| DTC No.  | DTC Detecting Condition           | Trouble Area       |
|----------|-----------------------------------|--------------------|
| C1223/43 | Malfunction in ABS control system | ABS control system |

## INSPECTION PROCEDURE

|          |                                  |
|----------|----------------------------------|
| <b>1</b> | <b>CHECK DTC(FOR ABS SYSTEM)</b> |
|----------|----------------------------------|

- (a) Clear the DTCs (see page [05-765](#) ).
- (b) Turn the ignition switch to the ON position.
- (c) Are the same DTCs recorded? (see page [05-765](#) )

**NO****PROCEED TO NEXT CIRCUIT INSPECTION  
SHOWN IN PROBLEM SYMPTOMS TABLE (SEE  
PAGE [05-786](#) )****YES****REPAIR CIRCUIT INDICATED BY OUTPUT DTC**