

OPERATION CHECK

1. ILLUMINATED ENTRY SYSTEM OPERATION CHECK

- (a) Illuminated entry system controls the following lamps:
 - Ignition key cylinder lamp
 - Interior lamp (Room lamp assy No.1)
 - Personal lamp (Overhead J/B)
- (b) Check that the lamps come on after:
 - (1) Unlocking any door that was closed and locked with the ignition switch off.
- (c) Check that the lamps fade out after:
 - (1) Leaving the doors unlocked for 15 seconds
 - (2) Turning the ignition switch to the ACC or ON position
 - (3) Locking all the doors
- (d) Check that the lamps stay ON for at least 15 seconds after opening any of the doors, then fade out again after 15 seconds.
- (e) Check that the lamps fade out after:
 - (1) Leaving the doors unlocked for 15 seconds
 - (2) Locking all the doors
- (f) Check that the lamps stay ON for at least 15 seconds after opening any of the doors, then fade out again in 15 seconds after closing all the doors.
- (g) Check that the lamps come on when opening any of the doors or turning the ignition switch off from the ACC or ON position.

2. LIGHT AUTO TURN OFF OPERATION CHECK

- (a) Turn the ignition switch to the ON position, and switch the headlamps into the TAIL or HEAD position.
- (b) Turn the ignition switch off and open the driver's door, and check that the headlamps go off immediately.
- (c) Turn the ignition switch to the ON position, and switch the headlamps into the AUTO position.
- (d) Turn the ignition switch off and open the driver's door when operating the automatic light control system, and check that the headlamps go off immediately.

3. AUTOMATIC LIGHT CONTROL OPERATION CHECK

HINT:

Perform the operation check at a location with bright surroundings.

- (a) Turn the ignition switch to the ON position.
- (b) Turn the headlamp dimmer switch to the AUTO position.
- (c) Cover the automatic light control sensor and check that the taillamp and headlamp in order.
- (d) Uncover the automatic light control sensor and check that the headlamp and taillamp go off in order.

4. DAYTIME RUNNING LIGHT OPERATION CHECK

- (a) Check that the high beams come on when the headlamp switch is off with the engine running and parking brake released.
- (b) Check that the high beams go off when turning the headlamp dimmer switch into the TAIL or HEAD (LOW) position under the condition as shown in (a).
- (c) Check that the high beams go off when turning the ignition switch off under the condition as shown in (a).