

REPLACEMENT

HINT:













COMPONENTS: SEE PAGE 71-6

1. TABLE OF BOLT, SCREW AND NUT

HINT:

The bolts, screws and nuts necessary for installation and removal of the instrument panel, are illustrated below and alphabetically coded.

mm (in.) (L = Length)

Code	Shape	Code	Shape	Code	Shape
<A>	 <p>$\phi = 5$ (0.20) L = 16 (0.63)</p> <p>93567 - 15016</p>		 <p>$\phi = 5.22$ (0.21) L = 16 (0.63)</p> <p>93567 - 55016</p>	<C>	 <p>$\phi = 6$ (0.24) L = 16 (0.63)</p> <p>90119-06144</p>
<D>	 <p>$\phi = 6$ (0.24) L = 25 (0.98)</p> <p>91635-60625</p>	<E>	 <p>$\phi = 6$ (0.24) L = 20 (0.79)</p> <p>90119 - 06251</p>	<F>	 <p>$\phi = 6$ (0.24) L = 20 (0.79)</p> <p>91635-60620</p>
<G>	 <p>$\phi = 8$ (0.32) L = 20 (0.79)</p> <p>91635 - 60820</p>	<H>	 <p>$\phi = 6$ (0.24) L = 20 (0.79)</p> <p>91513 - 60625</p>	<I>	 <p>$\phi = 6$ (0.24)</p> <p>90179 - 06097</p>
<J>	 <p>$\phi = 5$ (0.20) L = 18.5 (0.73)</p> <p>90159-50287</p>	<K>	 <p>$\phi = 6$ (0.24) L = 18 (0.71)</p> <p>91515-60618</p>	<L>	 <p>$\phi = 6$ (0.24) L = 16 (0.63)</p> <p>92615-00616</p>

P

B78418

2. DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60-1)
3. PLACE FRONT WHEELS FACING STRAIGHT AHEAD
4. REMOVE STEERING WHEEL COVER LOWER NO.2
5. REMOVE STEERING WHEEL COVER LOWER NO.3
6. REMOVE HORN BUTTON ASSY (SEE PAGE 60-17)


2005 HIGHLANDER REPAIR MANUAL (RM1144U)

Author :

Date :

3601

7. **REMOVE STEERING WHEEL ASSY (SEE PAGE 50-8)**
SST 09950-50013 (09951-05010, 09952-05010, 09953-05020, 09954-05021)
8. **REMOVE STEERING COLUMN COVER LWR (SEE PAGE 50-8)**
9. **REMOVE STEERING COLUMN COVER UPR (SEE PAGE 50-8)**
10. **REMOVE HEADLAMP DIMMER SWITCH ASSY (SEE PAGE 65-25)**
11. **REMOVE WINDSHIELD WIPER SWITCH ASSY (SEE PAGE 66-16)**



12. REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSY CENTER


- (a) Using a moulding remover, disengage the 8 clips.
- (b) Disconnect the connectors, then remove the instrument cluster finish panel sub-assy center.

HINT:

Set the shift lever in the N position.


13. REMOVE INTEGRATION CONTROL & PANEL ASSY (W/O NAVIGATION SYSTEM) (SEE PAGE 55-26)

14. REMOVE MULTI-DISPLAY (CRT DISPLAY) DISPLAY (W/ NAVIGATION SYSTEM) (SEE PAGE 67-8)




15. REMOVE INSTRUMENT PANEL FINISH PANEL LOWER

- (a) Using a moulding remover, disengage the 5 clips.
- (b) Disconnect the connectors, then remove the instrument panel finish panel lower.




16. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSY

- (a) Using a moulding remover, disengage the 5 clips, then remove the instrument cluster finish panel assy.




17. REMOVE INSTRUMENT CLUSTER FINISH PANEL GARNISH

- Remove the 4 screws .
- Disengage the claw, then remove the instrument cluster finish panel garnish.




18. REMOVE COMBINATION METER ASSY

- Remove the 3 screws , then pull the combination meter assy.
- Disconnect the connectors, then remove the combination meter assy.




19. REMOVE INSTRUMENT PANEL FINISH PANEL SUB-ASSY LOWER

- Remove the 2 bolts <D>.
- Disengage the 3 clips.
- Disconnect the connectors.
- Disconnect the hood lock control cable, then remove the instrument panel finish panel sub-assy lower.



20. REMOVE INSTRUMENT PNL INSERT SUB- ASSY LWR LH

- Remove the 3 bolts <F> and the instrument panel insert sub-assy LWR LH.




21. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSY CENTER


- Using a moulding remover, disengage the 4 clips and the 2 claws.
- Disconnect the connectors, then remove the instrument cluster finish panel assy center.

HINT:

Set the shift lever in the N position.

**22. REMOVE FLOOR CARPET COVER CENTER LH**

- (a) Remove the 2 clips and the floor carpet cover center LH.


23. REMOVE FLOOR CARPET COVER CENTER RH**24. REMOVE FRONT SEAT ARMREST ASSY CENTER**

- (a) Using a screwdriver, disengage the 2 claws and remove the seat armrest cover LH.

HINT:

Tape the screwdriver tip, before use.


- (b) Remove the bolt and front seat armrest assy center.

**25. REMOVE CONSOLE BOX ASSY**


- (a) Cover the parts indicated in the illustration with protective tape to prevent them from being damaged.
- (b) Remove the 3 screws .
- (c) Remove the 2 console caps and the 2 screws <J>.
- (d) Remove the 2 bolts <K>.
- (e) Pull the console box assy towards the rear of the vehicle and disengage the 2 clips, and then remove the console box assy.

NOTICE:


Be careful not to damage the bottom of the instrument panel safety pad when removing the console box assy.

**26. REMOVE GLOVE COMPARTMENT DOOR ASSY**

- (a) Remove the glove compartment door damper clip.



- (b) Remove the 2 clips and the glove compartment door Assy.




27. REMOVE INSTRUMENT PANEL FINISH PANEL LOWER NO.2

- (a) Remove the 7 screws and the instrument panel finish panel lower No. 2.


- 28. DISCONNECT PASSENGER AIRBAG CONNECTOR (SEE PAGE 60-29)**
- 29. REMOVE FRONT PILLAR GARNISH LH (SEE PAGE 76-21)**
- 30. REMOVE FRONT PILLAR GARNISH RH (SEE PAGE 76-21)**
- 31. REMOVE FRONT DOOR SCUFF PLATE LH (SEE PAGE 76-21)**
- 32. REMOVE FRONT DOOR SCUFF PLATE RH (SEE PAGE 76-21)**
- 33. REMOVE COWL SIDE TRIM SUB-ASSY LH (SEE PAGE 76-21)**
- 34. REMOVE COWL SIDE TRIM SUB-ASSY RH (SEE PAGE 76-21)**

35. REMOVE INSTRUMENT PANEL SAFETY PAD SUB-ASSY W/PASSENGER AIR BAG ASSY

- (a) Disconnect the connectors.



- (b) Remove the 7 bolts <C> <E> <G> and the nut <I>.
- (c) Disengage the 3 pins, then remove the instrument panel safety pad sub-assy.



36. REMOVE INSTRUMENT CLUSTER FINISH PANEL GARNISH NO.2

- (a) Disengage the 4 clips, then remove the instrument cluster finish panel garnish No. 2.

37. REMOVE AUTOMATIC LIGHT CONTROL SENSOR

- (a) Disconnect the connector.
(b) Remove the automatic light control sensor.

38. REMOVE COOLER (SOLAR SENSOR) THERMISTOR

- (a) Disconnect the connector.
(b) Remove the cooler (solar sensor) thermistor.

NOTICE:

Do not pry the cooler (solar sensor) thermistor off from the upper position.

39. REMOVE INSTRUMENT PANEL PIN NO.1

- (a) Remove the 3 screws and the 3 instrument panel pin No.1.

40. REMOVE DEFROSTER NOZZLE ASSY

- (a) Remove the 7 screws <A> and the defroster nozzle assy.

41. REMOVE SIDE DEFROSTER NOZZLE DUCT NO.1

- (a) Remove the screw <A> and the defroster nozzle duct No. 1.

42. REMOVE SIDE DEFROSTER NOZZLE DUCT NO.2

- (a) Remove the screw <A> and the side defroster nozzle duct No. 2.

43. REMOVE HEATER TO REGISTER DUCT NO.1

- (a) Remove the clip.
(b) Remove the 3 screws <A> and the heater to register duct No. 1.

44. REMOVE HEATER TO REGISTER DUCT NO.4

- (a) Remove the clip.
(b) Remove the 3 screws <A> and the heater to register duct No. 4.

45. REMOVE HEATER TO REGISTER CENTER SUB DUCT

- (a) Remove the 4 screws <A> and the heater to register center sub duct.

46. REMOVE INSTRUMENT PANEL REGISTER ASSY LOWER NO.1

- (a) Remove the 2 screws <A> and the instrument panel register assy lower No. 1.

47. REMOVE INSTRUMENT PANEL REGISTER ASSY NO.1

- (a) Remove the 2 screws <A> and the instrument panel register assy No. 1.

48. REMOVE INSTRUMENT PANEL BRACKET SUB-ASSY CENTER


- (a) Remove the 3 screws <A> and the instrument panel bracket sub-assy center.

49. REMOVE NAVIGATION ANTENNA ASSY (W/ NAVIGATION SYSTEM) (SEE PAGE 67-19)**50. REMOVE INSTRUMENT PANEL WIRE****51. REMOVE INSTRUMENT PANEL PASSENGER AIR BAG ASSY (SEE PAGE 60-29)****52. REMOVE INSTRUMENT PANEL SAFETY PAD SUB-ASSY**

53. **INSTALL INSTRUMENT PANEL PASSENGER AIR BAG ASSY (SEE PAGE 60-29)**
 54. **INSTALL INSTRUMENT PANEL SAFETY PAD SUB-ASSY W/PASSENGER AIR BAG ASSY**
 (a) Install the 7 bolts <C> <E> <G>, nut <I> with the instrument panel safety pad sub-assy.

Torque:

Bolt <G>: 20 N·m (204 kgf·cm, 15 ft·lbf)



55. **INSTALL FRONT SEAT ARMREST ASSY CENTER**
 56. **CENTER SPIRAL CABLE (SEE PAGE 60-26)**
 57. **INSTALL STEERING WHEEL ASSY (SEE PAGE 50-8)**
 58. **INSPECT STEERING WHEEL CENTER POINT**
 59. **INSTALL HORN BUTTON ASSY (SEE PAGE 60-17)**
 60. **CONNECT BATTERY NEGATIVE TERMINAL**
 61. **INSPECT HORN BUTTON ASSY (SEE PAGE 60-1 1)**
 62. **INSPECT SRS WARNING LIGHT (SEE PAGE 05-1207)**