


MULTI-DISPLAY CONTROLLER SUB-ASSY REPLACEMENT

67163-01


HINT:

- COMPONENTS: See page 67-2
 - Installation is in the reverse order of removal.
1. REMOVE REAR SEAT ASSY RH (SEE PAGE 72-35)
 2. REMOVE REAR SEAT ASSY LH (SEE PAGE 72-28)
 3. REMOVE REAR DOOR SCUFF PLATE RH (SEE PAGE 76-21)
 4. REMOVE REAR DOOR SCUFF PLATE LH (SEE PAGE 76-21)
 5. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP RH (SEE PAGE 76-21)
 6. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP LH (SEE PAGE 76-21)
 7. REMOVE TONNEAU COVER ASSY (SEE PAGE 76-21)
 8. REMOVE DECK BOARD SUB-ASSY (SEE PAGE 76-21)
 9. REMOVE DECK BOARD SUB-ASSY NO.2 (SEE PAGE 76-21)
 10. REMOVE DECK BOARD SUB-ASSY NO.3 (SEE PAGE 76-21)
 11. REMOVE DECK SIDE TRIM BOX RH (SEE PAGE 76-21)
 12. REMOVE DECK SIDE TRIM BOX LH (SEE PAGE 76-21)
 13. REMOVE REAR FLOOR FINISH PLATE (SEE PAGE 76-21)
 14. REMOVE DECK TRIM SIDE PANEL ASSY RH (SEE PAGE 76-21)
 15. REMOVE DECK TRIM SIDE PANEL ASSY LH (SEE PAGE 76-21)




16. REMOVE REAR SEAT SUB FLOOR PANEL ASSY (W/O RR NO.2 SEAT)

- (a) Remove the 3 bolts, 3 nuts and rear seat sub floor panel.




17. REMOVE MULTI-DISPLAY CONTROLLER W/BRACKET



- (a) Disconnect the connectors.
- (b) W/o RR No.2 Seat:
Remove the 2 bolts and nut and the multi-display controller w/bracket.




- (c) W/ RR No.2 Seat:
Remove the 2 nuts and bolt and the multi-display controller w/bracket.



- 18. REMOVE MULTI-DISPLAY CONTROLLER BRACKET A**
(a) Remove the 2 screws and the multi-display controller bracket A.



- 19. REMOVE MULTI-DISPLAY CONTROLLER BRACKET B**
(a) Remove the 2 screws and the multi-display controller bracket B.



20. REMOVE MULTI-DISPLAY CONTROLLER SUB-ASSY