


# FRONT NO.2 SPEAKER ASSY REPLACEMENT

6715V-01

**HINT:**

- COMPONENTS: See page 67-2
  - Installation is in the reverse order of removal.
1. REMOVE MULTIPLEX NETWORK MASTER SWITCH ASSY (SEE PAGE 75-6 )
  2. REMOVE FRONT DOOR LOWER FRAME BRACKET GARNISH LH (SEE PAGE 75-6 )
  3. REMOVE DOOR PULL HANDLE (SEE PAGE 75-6 )
  4. REMOVE FRONT DOOR TRIM BOARD SUB-ASSY LH (SEE PAGE 75-6 )
  5. REMOVE FRONT DOOR INSIDE HANDLE SUB-ASSY LH (SEE PAGE 75-6 )



6. REMOVE FRONT NO.2 SPEAKER ASSY
  - (a) Disconnect the connector.
  - (b) Remove the screw and front No. 2 speaker assy.