


MULTI-DISPLAY (CRT DISPLAY) DISPLAY REPLACEMENT

6715S-01


HINT:

- COMPONENTS: See page [67-2](#)
- Installation is in the reverse order of removal.


1. REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSY CENTER (SEE PAGE [71-10](#))



- ## 2. REMOVE INTEGRATION CONTROL & PANEL ASSY
- Remove the 6 bolts.
 - Disconnect the connectors and remove the integration control & panel assy.



- ## 3. REMOVE MULTI-DISPLAY CONTROLLER BRACKET A
- Remove the 7 screws and multi-display controller bracket A.



- ## 4. REMOVE MULTI-DISPLAY CONTROLLER BRACKET B
- Remove the 7 screws and multi-display controller bracket B.

5. REMOVE MULTI-DISPLAY (CRT DISPLAY) DISPLAY

6. INSTALL MULTI-DISPLAY (CRT DISPLAY) DISPLAY

HINT:

Perform the screen noise automatic adjustment when screen noise occurs (see page [05-1803](#)).