

PROBLEM SYMPTOMS TABLE

WIPER AND WASHER SYSTEM

Symptom	Suspected Area	See page
Front wipers and washers do not operate.	1. WIPER/WASHER Fuse 2. Front Wiper Switch 3. Wire Harness or Connector	- 66-4 -
Front wipers do not operate in LO or HI.	1. WIPER Fuse 2. Front Wiper Switch 3. Front Wiper Motor 4. Wire Harness or Connector	- 66-4 66-4 -
Front wipers do not operate in INT.	1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness or Connector	66-4 66-4 -
Front washer motor does not operate.	1. WASHER Fuse 2. Front Washer Switch 3. Front Washer Motor 4. Wire Harness or Connector	- 66-4 66-3 -
Front wipers do not operate when washer switch is ON.	1. Front Wiper Switch 2. Front Wiper Motor 3. Wire Harness or Connector	66-4 66-4 -
Rear wipers and washers do not operate.	1. RR WIP Fuse 2. Rear Wiper and Washer Switch 3. Wire Harness or Connector	- 66-4 -
Rear wipers do not operate in INT.	1. Rear Wiper and Washer Switch 2. Rear Wiper Motor 3. Wire Harness or Connector	66-4 66-4 -
Rear washer motor does not operate.	1. WASHER Fuse 2. Rear Wiper and Washer Switch 3. Rear Washer Motor 4. Wire Harness or Connector	- 66-4 66-3 -
Rear wipers do not operate when washer switch is ON.	1. Rear Wiper and Washer Switch 2. Rear Wiper Motor 3. Wire Harness or Connector	66-4 66-4 -
Washer fluid does not operate.	1. Washer Hose and Nozzle	-
● When the wiper switch is OFF, the wiper blade does not retract or the retract position is wrong.	1. *1Wiper Motor	66-7
Washer fluid level warning does not operate.	1. Level Warning Switch Assy 2. Combination Meter Assy 3. Wire Harness or Connector	66-7 05-1882 -

*1: Inspect wiper arm and blade set position