


OVERHAUL

HINT:

COMPONENTS:


SHIFT LEVER ASSY (See page 40-61)

1. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSY CENTER (SEE PAGE 71-10)
2. REMOVE FLOOR CARPET COVER CENTER RH (SEE PAGE 71-10)
3. REMOVE FLOOR CARPET COVER CENTER LH (SEE PAGE 71-10)
4. REMOVE CONSOLE BOX ASSY (SEE PAGE 71-10)




5. DISCONNECT TRANSMISSION CONTROL CABLE ASSY

- (a) Disconnect the floor shift transmission control cable assy end from the floor shift assy.




6. REMOVE FLOOR SHIFT ASSY

- (a) Disconnect the 3 connectors.
- (b) Remove the 4 nuts and dismount the floor shift assy from the vehicle.




7. REMOVE SHIFT LEVER KNOB SUB-ASSY

- (a) Releasing the lock by pressing the click, disconnect the indicator lamp wire connector from the shift lever plate.




- (b) Using a screwdriver, release the stopper of the connector.
- (c) Using a small screwdriver, disengage the locking lug of the terminals 2 and 6, and pull the terminals out from the rear.
- (d) Disconnect the 2 wire harnesses of the transmission control switch from the clamp.



- (e) Lower the shift lever knob cover.
- (f) Remove the 2 screws and shift lever knob from the shift lever.


8. REMOVE FLOOR SHIFT SHIFT LEVER KNOB COVER

- (a) Remove the shift lever knob cover from the shift lever.




9. REMOVE SHIFT LEVER KNOB BUTTON

- (a) Using a screwdriver, release the claw and remove the shift lever knob button and spring from the shift lever knob.




10. REMOVE TRANSMISSION CONTROL SWITCH

- (a) Remove the screw from the shift lever knob, detach the transmission control switch together with the shift lever knob cover No.1.




- (b) Using a screwdriver, release the 2 claws and remove the transmission control switch from the shift lever knob cover No.1.




11. REMOVE INDICATOR LAMP WIRE SUB-ASSY

- (a) Using a screwdriver, release the stopper of the connector.
- (b) Using a small screwdriver, disengage the locking lug of the terminals 3 and 7, and pull the terminals out from the rear.




- (c) Remove the indicator lamp wire from the position indicator housing lower.
- (d) Remove the indicator lamp cap and indicator lamp bulb from the indicator lamp wire.




12. REMOVE SHIFT LOCK RELEASE BUTTON COVER

- (a) Using a small screwdriver, remove the shift lock release cover from the control position indicator plate.




13. REMOVE CONTROL POSITION INDICATOR PLATE

- (a) Using a screwdriver, release the 4 claws and remove the control position indicator plate from the position indicator housing lower.




14. REMOVE POSITION INDICATOR HOUSING LOWER

- (a) Remove the 4 screws, detach the position indicator housing lower from the shift lever plate.




15. REMOVE SHIFT LOCK RELEASE BUTTON

- (a) While pressing the 2 claws, remove the shift lock release button and spring from the position indicator housing lower.




16. REMOVE PATTERN SELECT SWITCH ASSY NO.1

- (a) Using a screwdriver, release the 4 claws and remove the pattern select switch assy No.1 from the position indicator housing lower.




17. REMOVE POSITION INDICATOR HOUSING UPPER

- (a) Using a screwdriver, release the 4 claws and remove the position indicator housing upper from the position indicator housing lower.




18. REMOVE POSITION INDICATOR SLIDE COVER

- (a) Remove the position indicator slide cover from the position indicator housing lower.
- (b) Remove the position indicator light guide from the position indicator lower.




19. REMOVE POSITION INDICATOR SLIDE COVER


- (a) Remove the position indicator slide cover No.2 from the position indicator slide cover.

**20. REMOVE TRANSMISSION SHIFT MAIN SWITCH**


- (a) Remove the screw and transmission shift main switch from the position indicator housing lower.

**21. REMOVE SHIFT LEVER KNOB SLEEVE**


- (a) Remove the shift lever knob sleeve from the shift lever.

**22. INSTALL SHIFT LEVER KNOB SLEEVE**


- (a) Apply MP grease to the shown part of the shift lever knob sleeve and install it to the shift lever.

**23. INSTALL TRANSMISSION SHIFT MAIN SWITCH**


- (a) Install the transmission shift main switch to the position indicator housing lower with the screw.

**24. INSTALL POSITION INDICATOR SLIDE COVER**


- (a) Install the position indicator slide cover No.2 to the position indicator slide cover.

**25. INSTALL POSITION INDICATOR SLIDE COVER**

- (a) Install the position indicator slide cover to the position indicator housing lower.
- (b) Install the position indicator light guide to the position indicator housing lower.

**26. INSTALL POSITION INDICATOR HOUSING UPPER**


- (a) Install the position indicator housing upper to the position indicator housing lower.

**27. INSTALL PATTERN SELECT SWITCH ASSY NO.1**

- (a) Install the pattern select switch assy No. 1 to the position indicator housing lower.

HINT:


Fit the claws securely.

**28. INSTALL SHIFT LOCK RELEASE BUTTON**


- (a) Install the shift lock release button and greased spring to the position indicator housing lower.

HINT:

Fit the claws securely.

**29. INSTALL POSITION INDICATOR HOUSING LOWER**

- (a) Install the position indicator housing lower to the shift lever plate with 4 screws.




30. INSTALL CONTROL POSITION INDICATOR PLATE

- (a) Install the control position indicator plate to the position indicator housing lower.


HINT:

Fit the claws securely.




31. INSTALL SHIFT LOCK RELEASE BUTTON COVER

- (a) Install the shift lock release cover to the control position indicator plate.



32. INSTALL INDICATOR LAMP WIRE SUB-ASSY

- (a) Install the indicator lamp bulb and indicator lamp cap to the indicator lamp wire.
- (b) Install the indicator lamp wire to the position indicator housing lower.




33. INSTALL TRANSMISSION CONTROL SWITCH


- (a) Install the transmission control switch to the shift lever knob cover No.1.

HINT:

Fit the claws securely.




- (b) Install the shift lever knob cover No.1 to the shift lever knob with a screw.

**34. INSTALL SHIFT LEVER KNOB BUTTON**


- (a) Apply MP grease to the shift lever knob button and spring and install them to the shift lever knob.

35. INSTALL SHIFT LEVER KNOB COVER NO.1


- (a) Install the shift lever knob cover to the shift lever.

**36. INSTALL SHIFT LEVER KNOB SUB-ASSY**


- (a) Install the wire harness of the transmission control switch as shown in the illustration.



- (b) Install the shift lever knob to the shift lever with 2 screws.
 (c) Install the shift lever knob cover to shift lever knob.
 (d) Install the 2 wire harnesses of the transmission control switch.



- (e) Install the indicator lamp wire harness and connector as shown in the illustration.

**37. INSTALL FLOOR SHIFT ASSY**


- (a) Install the floor shift assy to the vehicle with the 4 nuts.

Torque: 12 N·m (122 kgf·cm, 9 ft·lbf)

HINT:

Tighten them in the order, A, B, C and D.

- (b) Connect the 3 connectors.

**38. INSTALL TRANSMISSION CONTROL CABLE ASSY**

- (a) Connect the floor shift transmission control cable end to the floor shift assy.

HINT:

Install it with the uneven surface facing up.

39. INSPECT SHIFT LEVER POSITION (SEE PAGE 40-71)**40. ADJUST SHIFT LEVER POSITION (SEE PAGE 40-71)**