




CHARCOAL CANISTER ASSY (3MZ-FE) REPLACEMENT

120E7-01


1. **REMOVE EXHAUST PIPE ASSY CENTER**
 - (a) Remove the 4 bolts and 4 compression springs.
 - (b) Remove the exhaust pipe center from the 4 exhaust pipe supports.
 - (c) Remove the 2 gaskets from the exhaust pipe front No. 3 and the exhaust pipe center.




2. **REMOVE FRONT FLOOR HEAT INSULATOR NO.3**
 - (a) Remove the 4 bolts and heat insulator.



3. **REMOVE CHARCOAL CANISTER ASSY**
 - (a) Disconnect the VSV connector for CCV.
 - (b) Disconnect the fuel emission hose.
 - (c) Disconnect the air inlet line hose.




- (d) Disconnect the fuel tank vent hose.
- (1) Push the connector deeply into the charcoal canister assy to release the locking tab.
 - (2) Pinch portion A.
 - (3) Pull out the connector.



- (e) Remove the 3 nuts, and then remove the charcoal canister.


4. INSTALL CHARCOAL CANISTER ASSY

- (a) Install the charcoal canister with the 3 nuts.
Torque: 5.5 N·m (56 kgf·cm, 49 in.-lbf)



5. INSTALL FRONT FLOOR HEAT INSULATOR NO.3

- (a) Install the heat insulator with the 4 nuts.
Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)



6. INSTALL EXHAUST PIPE ASSY CENTER


- (a) Using a vernier caliper, measure the free length of the compression spring.

Minimum length:

41.5 mm (1.634 in.) for center to front No. 3

40.5 mm (1.594 in.) for center to tail

If the free length is less than minimum, replace the compression spring.



- (b) Install 2 new gaskets to the exhaust pipe front No. 3 and the exhaust pipe center as shown in the illustration.
- (c) Install the exhaust pipe center to the 4 exhaust pipe supports.
- (d) Install the 4 compression springs and 4 bolts.
Torque: 48 N·m (489 kgf·cm, 35 ft·lbf)

7. CHECK EXHAUST LEAKAGE

If gas is leaking, tighten the areas necessary to stop the leak.
If damaged, replace it.